

**RECOMMENDED WELL HEAD  
PROTECTION PROGRAM**

**Village of Finch  
Municipal Wells**

Prepared for:

**TOWNSHIP OF NORTH STORMONT**

2 Berwick Victoria Street  
P.O. Box 99  
Berwick, Ontario  
K0C 1G0



**Water and Earth Science Associates Ltd.**  
Box 430, 3108 Carp Road  
Carp, Ontario, K0A 1L0

July 2005

Project No. C-B3018

## TABLE OF CONTENTS

<b>1.0</b>	<b>INTRODUCTION .....</b>	<b>1</b>
<b>2.0</b>	<b>SITE DESCRIPTION, GEOLOGY, HYDROGEOLOGY &amp; WELL CONSTRUCTION DETAILS .....</b>	<b>2</b>
2.1	Site Description.....	2
2.2	Geology .....	3
2.3	Hydrogeology .....	3
2.4	Well Construction Details.....	4
<b>3.0</b>	<b>WELL HEAD PROTECTION PLAN (WHPP) .....</b>	<b>6</b>
3.1	Delineation of the Groundwater Capture Areas and Determination of the Groundwater Intrinsic Susceptibility.....	7
3.2	Local Refining of Municipal Well Head Protection Areas (WHPA)	10
3.3	Intrinsic Susceptibility and Contaminant Source Inventory Within the WHPA.....	12
3.3.1	Land-Use Risk Rating.....	15
3.4	Groundwater Source Protection Plan.....	16
3.4.1	Elements of the Groundwater Source Protection Action Plan	16
3.4.1.1	Risk Management Strategies.....	16
3.4.1.2	Risk Ranking & Associated Risk Management Strategies.....	17
3.4.2	Implementation of Well Head Protection Strategy.....	17
3.4.2.1	Risk Avoidance .....	18
3.4.2.2	Risk Management .....	19
3.4.2.3	Awareness (Education and Training).....	22
3.4.3	Summary of Action Plan Strategies.....	24
<b>4.0</b>	<b>RECOMMENDED WATER SUPPLY WELL MONITORING PROGRAM .....</b>	<b>27</b>
4.1	Review of Historical Site Reports.....	28
4.2	Groundwater Quality Monitoring Program .....	33
4.3	Well Inspection Program .....	35
<b>5.0</b>	<b>CONCLUSIONS .....</b>	<b>36</b>
<b>6.0</b>	<b>RECOMMENDATIONS.....</b>	<b>39</b>
<b>7.0</b>	<b>REFERENCES .....</b>	<b>44</b>

## LIST OF TABLES

Table 1:	Well Construction Summary
Table 2:	List of Potential Contaminant Sources
Table 3:	Land Use Risk Rating Matrix
Table 4:	Implementation of Well Head Protection Strategy
Table 5:	Evaluation of Protection Methods
Table 6:	Summary of Reported Total Coliform Raw Water Quality

## LIST OF FIGURES

Figure 1:	Site Location Map
Figure 2:	Aquifer Intrinsic Susceptibility and Wellhead Protection Areas – Surrounding Area
Figure 3A:	Potential Contaminant Sources in the Village of Finch
Figure 3B:	Potential Contaminant Sources in Surrounding Area
Figure 4:	Land-Use Risk Rating Map

## LIST OF APPENDICES

Appendix A:	EOWRC 2003 Report: Figure 5.1, Wellhead Protection Areas And Aquifer Intrinsic Susceptibility Map
Appendix B:	Municipal Wells – MOE Well Records
Appendix C:	Hazard Ratings For Potential Contaminant Sources (EOWRC Report 2003, Table 5.1)
Appendix D:	Evaluation Ranking System Of Potential Risk For Contaminant Sources (EOWRC 2003 Report: Pages 71-72)
Appendix E:	Township Of North Stormont: Zoning By-Law Map Of Area
Appendix F:	Risk Strategies Implemented By Other Ontario Municipalities
Appendix G:	MOE Terms Of Reference Questionnaires And Examples Of Best Management Practices For Industry And Commercial Establishments
Appendix H:	Well Log Summary and Location Map Of Village Of Finch Wells
Appendix I:	Photo Log

## 1.0 INTRODUCTION

The Township of North Stormont contracted Water and Earth Science Associates Ltd. (WESA), of Carp, Ontario to prepare a recommended Well Head Protection Plan (WHPP) for the village of Finch Municipal Wells. The Ministry of Environment's Certificate of Approval (C of A) for the water supply system requires "the implementation of a WHPP to monitor aquifer conditions and to identify and protect the area of recharge of the wells from the risk of man-made activities". This includes potential adverse impacts due to existing and future land use.

The main components of the WHPP include the following:

1. Delineation of Wellhead Protection Areas – Well Capture Zones
2. Development of a Land Use Risk Rating Map (Using the Well Capture Zones)
3. Provide direction for appropriate wellhead and aquifer protection strategies, and
4. Development of an Aquifer Monitoring Program.

The Village of Finch is located in Southeastern Ontario, in the Township of North Stormont about 20 km east of Cornwall, Ontario and 16 km north of the 401 along CR12 where CR12 intercepts HWY 43, just west of the Payne River. The following provides a recommended Well Head Protection Program (WHPP) for the Village of Finch Municipal wells. The study area for this project includes the Village of Finch, an area encompassing approximately 500 m around the Village of Finch communal water wells, as well as key areas south of the village. A plan showing the study area, municipal and observational well locations and the Site is provided as Figure 1.

A program to implement wellhead protection strategies for the United Counties of Stormont, Dundas and Glengarry, the United Counties of Prescott & Russell, and the City of Ottawa has been carried out by the Eastern Ontario Water Resources Committee (EOWRC). The definition of Wellhead Protection Areas (WHPAs) for the Village of Finch Municipal wells and recommended measures for a wellhead protection strategy for the defined areas are provided in *Municipal Groundwater Study, Township of North Stormont, Prepared for the Eastern Ontario Water Resources Committee, October 2003* prepared by Robinson Consultants Inc. et al., hereafter referred to as the EOWRC report.

The WHPAs and Aquifer Intrinsic Susceptibility Map for the Finch Municipal Wells as determined in the EOWRC report is provided in Appendix A for reference. Input data used in the modeling and delineation of the WHPAs was not available for review during preparation of the WHPP.

## **2.0 SITE DESCRIPTION, GEOLOGY, HYDROGEOLOGY & WELL CONSTRUCTION DETAILS**

### **2.1 SITE DESCRIPTION**

The Village of Finch well site is located on the north-western edge of the village at #20 William Street, just north of John Street. The Site is bordered by the community centre and arena parking lot to the south, William Street to the west, a commercial property to the north and the community arena building to the east. The municipal wells and treatment system are contained in a facility building.

Neighbouring land use consists of low density residential and commercial to the south and east beyond the community arena, farmland to the west and a sandblasting operation to the northwest (previously a small foam insulation industry), and a welding shop with fuel storage is located just north of the well heads. George Street runs along the east side of the community arena. To the west side of George Street is vacant property. East of this property is more residential and commercial properties located along CR12.

Access to the Site is via William Street. No fencing or gate entrance is present to control access to the Site. Two Municipal wells are located inside a secured building. Two additional wells, one located at the SD&G United Counties Building located on Front St east (adjacent to Payne Creek) and the other located at the Canada Post Office on Main St. are present in vicinity of the Municipal wells. Another well is known to have been historically located on Lot 14, 30 m north of HWY 43 and 91 m east of CR12. These wells could be used as bedrock observation wells if they can be located and their integrity and construction can be confirmed. It is known at this time that the well at the Counties Bldg is currently located below grade, and requires that the well casing extended before it can be used for monitoring purposes.

From quarterly reports on drinking water quality prepared by Ontario Clean Water Agency(OCWA), the total design capacity for the Finch Water Treatment Plant and Distribution System is 778 cubic metres per day, and services a population of 441 residents. Groundwater is pumped from the two municipal wells through an aeration tower at a rate of 9.5 litres/second for hydrogen sulphide removal. Sodium hypochlorite is subsequently added to the water for disinfection prior to entering a 20 cubic metre clear well. Two high lift pumps (one active, one on standby) pump the chlorinated water from the clear well through dual media pressure filters to a 580 cubic metre capacity storage tank for distribution. The 2003 annual report described system upgrades including improved chemical storage and spill containment for the sodium hypochlorite feed system.

From the 2001 engineering report prepared by Kostuch Engineering Limited, the present water treatment system has been in operation since the early 1980's.

## 2.2 GEOLOGY

The town is situated on unconsolidated deposits consisting primarily of a till plain with minor sand and gravel overlying the limestone bedrock of the Verulam Formation. The till is periodically overlain by discontinuous deposits of silty clay. Bedrock can be found to outcrop to the east of the village along the Payne River (Robinson Consultants Ltd. Et al.).

## 2.3 HYDROGEOLOGY

A hydrogeological assessment completed as part of the *Municipal Groundwater Study* indicates that the regional groundwater flow direction within the bedrock aquifers is towards the northwest. However, local groundwater flow direction is also likely influenced by the Payne River and local topography. The bedrock surface that slopes southeast towards a bedrock channel which strikes northeast-southwest between Newington and Avonmore is also an influence on local groundwater flow.

No overburden observation wells have been constructed on or surrounding the site to confirm the direction of shallow groundwater flow through the overburden or bedrock/overburden contact zone.

## **2.4 WELL CONSTRUCTION DETAILS**

The Village of Finch municipal well site contains two municipal wells. The wells were drilled in 1972 by Ramon H. Casselman drilling contractors of Williamsburg, Ontario. The well records can be found in Appendix B. The aquifer from which the municipal well field draws its groundwater is located in an upper zone of the limestone bedrock located from 4.57 metres (15 feet) to 42.37 metres (139 feet) below the bedrock surface.

A well construction summary for the site wells is provided in Table 1 below.

Table 1: Well Construction Summary

Construction Details	Well #1	Well #2
Current Permit to Take Water (PTTW)	80-P-4002, renewal date March 31, 2010, 777.6 m <sup>3</sup> /day (lead/lag control arrangement)	
Legal Description	Part 2 of RP52R-1181, Twp. Of N. Stormont, United Counties of S, D and G	
UTM Easting:	492995 m E UTM NAD27, Zone 18, Accuracy: 100m	
UTM Northing:	4998745 m N UTM NAD27, Zone 18, Accuracy: 100m	
Depth to bedrock	3.35 metres	3.35 metres
Total Depth	57.61 m (27.6 masl)	57.61 m (27.6 masl)
Depth To Water Found from surface.	7.92m, 24.08m, 39.62m and 45.72m	19.51 metres
Depth to water bearing zone below bedrock surface	4.57m, 20.73m, 36.27m and 42.37m	16.16 metres
Well Screen Depth Interval	Open Hole for 49.07m	Open Hole for 49.07m
Well Screen slot size	N/A	N/A
Floor Elevation (masl)	81.65 masl	81.65 masl
Diameter of well	200mm	200 mm
TOC Elevation	83.73 masl	83.73 masl
Bottom of casing elevation	75.2 masl	75.2 masl
Type of Casing	steel 0.2 m inside diameter	
Depth of casing from ground surface	8.5 m	
Geological description	0-1.5 m fill 1.5 – 3.4 m gravel 3.4 – 57.6 m limestone	0-1.5 gravel clay fill 1.5 – 3.4 gravel 3.4 -30,2 m limestone solid 30.2 – 31.7 limestone broken 31.7 – 57.6 limestone solid
Current Operational Status	On Line	On Line



The well records state that the municipal wells are 200 mm in diameter. Both municipal wells are steel cased to a depth of 28 feet (17 feet into bedrock) according to the OWRC and MOE 1972 water well records, Appendix B). However the water well records do not indicate if the wells were ever grouted. Considering the construction date it is likely that they were not grouted to today's standards. The Municipal well facility is shown on Figure 1.

From WESA's visual inspection of the Water Treatment Plant, it is apparent that the Municipal wells are in a secure location, and the wellheads are protected from overland surface water runoff. They are located below ground surface in a basement area, however this area was dry at the time of the site visit and operators confirmed that the area did not flood.

### **3.0 WELL HEAD PROTECTION PLAN (WHPP)**

The simulated WHPAs for the Finch Municipal wells were delineated by Robinson Consultants Inc. et al. and are depicted in the EOWRC report, Figure 5.1. This figure is presented in Appendix A of this report. The EOWRC assessment indicates that the 50-day groundwater time of travel (TOT) area for the Municipal well site is situated within an 87.5 meter radius of the corner of John Street and William Street. The 2-year TOT area extends approximately 750 metres south beyond the boundaries of the Site, encompassing most of the Village south-southeast of the Site and extending onto agricultural land to the west and south-southeast. The 10-year and 25-year TOT areas extend several kilometres to the southeast. The aquifer intrinsic susceptibility index for the 50 day, the 2-year, the 10-year and the 25 year TOT areas are all "high" due to the thin, semi-permeable nature of the overburden material within the WHPAs (EOWRC report, 2003). The limits of these TOT areas were determined by Robinson Consultants Inc. et al based on their groundwater modelling of the region. WESA was not provided with the MOE well record database in order to review the derivation of these TOT areas.

An inventory of potential areas of contamination within the 500 meter radius of the Site was catalogued by WESA. By combining this information with the TOT areas developed in the EOWRC report, WESA identified areas of potential concern and greatest vulnerability with respects to groundwater impact. This information was then used as a tool to develop a strategy for groundwater protection. The steps towards developing a Groundwater Source Protection Plan for a site are listed below;

- Delineation of Groundwater Capture Areas as part of the Regional Plan (EOWRC report)
- Determination of Groundwater Intrinsic Susceptibility as part of the Regional Plan (EOWRC report)
- Site Specific Refining of Municipal Well Head Protection Areas
- Site Specific Contaminant Source Inventory
- Development of the Groundwater Source Protection Action Plan
- Aquifer Monitoring Program
- Conclusions
- Recommendations

### **3.1 DELINEATION OF THE GROUNDWATER CAPTURE AREAS AND DETERMINATION OF THE GROUNDWATER INTRINSIC SUSCEPTIBILITY**

The objective of identifying wellhead protection areas is to delineate areas of potential risk with respect to groundwater impact.

The groundwater capture zone is essentially the footprint encompassing the area from which groundwater flows toward the groundwater production well, in this case the municipal well field.

A groundwater study was undertaken by the Eastern Ontario Water Resources Committee (EOWRC) in 2001/2002 to define the Wellhead Protection Areas (WHPA) for the municipal well field of the town of Finch, Ontario. The numerical model MODFLOW was used to estimate groundwater capture zones. A description of the

model's underlying assumptions, selected input data and boundary conditions are included in Sections 4.7 and 4.8 of the EOWRC report titled "*Municipal Groundwater Study, Township of North Stormont*" (Robinson Consultants Inc. et al., October 2003). A summary of some of the model's features and limitations are described here to ensure the reader appreciates the value of the modelling results.

The reader should understand that all numerical models involve a series of approximations and compromises, in the sense that they constitute a somewhat simplified representation of on-site conditions. At the onset of any modelling exercise, a conceptual model should be developed that defines parameters such as the geometry of the geologic units (thickness and orientation), the hydraulic conductivity of those units, the porosity of each respective unit, and the boundary conditions. The boundary conditions for a groundwater flow model is either first type (when you assign a specific hydraulic head along the perimeter of the model) or second type (when you assign a specific groundwater flux across any side of the model).

The data used to generate the potentiometric surface originated from the MOE Well Records. This source of groundwater data provides an approximation on a regional scale, and is by no means accurate at any specific location. The model geometry (stratigraphy) is also derived from the MOE well records. A greater accuracy will be attained in areas where there is a greater density of MOE Well Records. Generally the density of wells decreases with distance from the town centres. The model results around the perimeter of the modelling domain, where the density of wells is lower, should be interpreted considering the data available. Hence the modelling results presented in the EOWRC report dated October 2003 should be relatively more representative for the 0 to 50 day and 50 day to 2 year WHPA since the density of well record information was greater nearer the well field. However, the results should be interpreted loosely, with the knowledge that every step included in the modelling exercise involved the *estimation* of parameters. Caution should therefore be used when interpreting the modelling results; these should be placed in context by considering the variable quality of the underlying data used in developing the models.

The groundwater source that supplies the Finch municipal well field is the limestone bedrock. The aquifer is intercepted by two open boreholes that capture water from a series of fractures encompassing a water bearing zone that extends from 4.5 metres (Well No. 1) or 16.5 metres (Well no. 2) below the bedrock surface. The EOWRC report stated that the main aquifer for the regional study area, including the Finch Site was a Contact Zone aquifer which included the overburden just above the bedrock and up to 10 metres within the bedrock (EOWRC report, October 2003). While the Finch Municipal Wells tap into this fracture zone, the Finch Well No. 1 Record identifies three more water bearing zones at 24.08, 39.62 and 45.72 metres below the bedrock surface. The Municipal Wells have open boreholes and therefore extract a combination of contact zone and deeper bedrock groundwater.

The EOWRC report's WHPAs are divided into four zones, corresponding to travel times (TOT) of less than 50 days, 50 days to 2 years, 2 to 10 years and 10 to 25 years.

The natural in-situ conditions that will lead to groundwater protection are sometimes referred to as the *Groundwater Intrinsic Susceptibility* (GwIS). The objective of estimating the Groundwater Intrinsic Susceptibility is to identify areas where contamination of the groundwater is more, or less, likely to occur based on the natural capacity of the overburden and bedrock to provide a natural barrier to potential contaminant movement. The value of GwIS is to be used as a general guide to determine appropriate land use, and/or best management practices for any particular site with the intent of long-term stewardship of the underlying groundwater resources. Section 5.4.1 of the EOWRC report (October 2003) assigns an intrinsic susceptibility rating of high for the entire Finch study area. A high rating was assigned due to the limited thickness of the overburden over the bedrock surface. Hazard ratings for each potential contaminant source site in the Village of Finch study area identified by the regional study are listed in Table 5.1 of the EOWRC report and are included in Appendix C for the reader's convenience.

The results of the modelling conducted by Robinson Consultants Inc. et al. were produced on a *Wellhead Protection Area Aquifer Intrinsic Susceptibility* map for the Finch municipal wells. This map is reproduced in (Appendix A). The diagram shows that

the groundwater capture zone is relatively elongated and strikes south-southeast along County Road 12. The map is not in full agreement with the statements made by Robinson Consultants Inc. et al. in the text of their report. In Section 5.7 of the EOWRC report, reproduced herein in Appendix D, only a high rating of groundwater intrinsic susceptibility (GwIS) was assigned to the study area while in Figure 5.1 of the same report high and moderate GwIS ratings were indicated. WESA therefore reviewed the MOE well record summary and historical hydro-geological reports (published and in-house) for the study area which noted that the overburden thickness increases to the southeast. Therefore, WESA has decided to concur with Figure 5.1 (EOWRC report) and assume two ratings of GwIS within the study area.

### **3.2 LOCAL REFINING OF MUNICIPAL WELL HEAD PROTECTION AREAS (WHPA)**

WESA's first step in developing the Wellhead Protection Plan (WHPP) was to verify the reasonableness of the shape of the well head protection areas, especially in regards to the 50 day and 2 year protection zones. From WESA's experience with the model used 'MODFLOW' it is known that many parameters within the model are highly sensitive, including the direction of groundwater flow. A small change to the groundwater flow direction in the model for instance, would likely result in a shift to the WHPA areas more to the east or west. Based on the knowledge that the modeling was done using regional based data collected over a 30 year period, that refining of parameters based on local conditions may not have been undertaken and that the EOWRC report assigns a 'high' Aquifer Intrinsic Susceptibility rating for the entire Finch study area some recommendations have been prepared by WESA with respect to local refining of the WHPA's. With the entire Finch study area ranked as 'high', and the possibility that local refining of the input data may shift the groundwater flow direction and hence WHPA boundaries, WESA felt it was important that the WHPA's assigned included all potential activities within the entire 'high' risk ranked area that could represent a risk to the aquifer. This approach based on generalized hydrogeologic considerations and professional judgement is accepted within the practice of wellhead protection area delineation, for example the U.S. Environmental Protection Agency *Guidelines for Delineation of Wellhead Protection Areas* (1987) considers this a protective approach to locally define WHPA's.

In their review, WESA also re-examined in-house reports completed in the area of Finch, Ontario, other historical reports for the Site and topographical maps for the study area to fine tune the boundaries of the WHPA's presented in the EOWRC study. A site visit was conducted on March 10, 2004 by WESA to ground truth some of the data collected in the reports. Based on the data review, and the site visit, WESA refined the 50 day and the 50 day to 2 year wellhead protection areas surrounding the communal wells site.

Since the input database used in the modeling was not available for review during preparation of the WHPP, WESA has taken a cursory review of the MOE well record summary and historical hydro-geological reports for the area (published and in-house). The general direction of groundwater flow within the bedrock contact zone aquifer is in a north-westerly direction for the study area. WESA has assumed that the data analysis by Robinson Consultants Inc et al. is a reasonable estimation based on data used in their model, however to develop the WHPP, WESA has added some additional conservatism to take into account more localized information.

Based on the southeast sloping bedrock surface and the decrease in thickness of overburden to the north and west of the Site, it is possible there is a component of groundwater flow from the northwest. Based on this, WESA recommends extending the 50 day contact zone, west and north by an additional 250 metres in order to encompass the northwest corner of Finch within the 0-50 day well head protection area. Additionally, given the low density of well record information south of the village and the limitations and assumptions adopted by the model, WESA recommends widening the eastern and western boundaries of the 50 day to 2 year, 2 year to 10 year and 10 year to 25 year WHPAs. This more conservative approach will ensure a more comprehensive well head protection zone for the local area and will add a factor of safety for the many moderate to high risk activities undertaken within the 'high' risk ranking of the entire Finch study area.

One final area of concern involves the buried esker deposits that are shown by the dotted area on Figure 5.1 (Appendix A). This esker deposit is believed to be part of the southern extent of the Berwick esker complex. The esker complex likely is hydraulically connected to the region's Contact Zone Aquifer (EOWRC October 2003 report, p. 23) and through WESA's hydrogeological investigations in the Chrysler Municipal Well Site, it was evident that the esker groundwater is not only hydraulically connected to the contact zone but acts as a recharge reservoir for the Contact Zone Aquifer. At the Chrysler

Site the horizontal direction of groundwater flow in the esker deposit was to the north, this may also be true of the esker deposit in the Finch area. In the Finch area there is a mineral extraction land use zoning located within this esker complex just southwest of the Finch Municipal Well Site and just west of the 2 to 10 year WHPA. Consequent to this information, WESA recommends extending the 2 to 10 year WHPA to encompass the area to the west zoned for mineral extraction land use.

A plan showing the amended Well Head Protection Areas for the Finch Well Site is found in Figure 2. This more conservative approach for assigning WHPA's is highly recommended by WESA in their professional judgement to ensure adequate protection of the municipal water supply source. It must be understood that the WHPA boundaries defined within this plan are based on the best available modelling data/analysis at the time of the WHPP preparation. Also, the modelling results from the EOWRC Report have not been officially adapted by the conservation authorities that commissioned the study. Consequently, the WHPA boundaries presented herein may be revised in future after further modelling/analysis has been conducted as part of the province's watershed-based Source Protection Planning initiatives.

### **3.3 INTRINSIC SUSCEPTIBILITY AND CONTAMINANT SOURCE INVENTORY WITHIN THE WHPA**

In addition to the document review, a field visit was conducted to augment the contaminant source inventory conducted within the Village of Finch. A list of identified potential contaminant sources is found in Table 2. The GwIS results are presented in Section 5.0 of the EOWRC report. An updated Land-Use Risk Rating is presented in Section 3.3.1 herein, based on the results presented in this section. On a regional level the EOWRC report assigned a high intrinsic susceptibility rating for the Finch municipal wells since the overburden cover is relatively permeable and thin in areas. Where the overburden thickness increased a moderate intrinsic susceptibility rating was assigned (see Appendix A).

An updated diagram displaying the location of all the identified potential sources of contamination is shown on Figures 3a and 3b along with the revised WHPA. A summary of the potential contaminant sources for each WHPA are given below.

**Table 2**  
**List of Potential Contaminant Sources**  
**Village of Finch Well Head Protection Plan Study**

Source #	Municipality	Land Use	Picture Number (see Appendix 1)	Historical, Current or Proposed Land Use	Potential Contaminant Source Rating	GwIS rating	Well Head Protection Zone	Land Use Risk Rating (LURR)
1	N. Stormont	Welding Shop and fuel storage (east side William St. just north of Well site)	1, 4 and 7	current	high	high	50 day	high
2	N. Stormont	Foam Insulation Manufacturer (west side William St.)	2 and 19	historical	high	high	50 day	high
3	N. Stormont	Sandblasting operation, fuel storage (same location as above)	2 and 19	current	high	high	50 day	high
4	N. Stormont	Industrial Zoned land (just north of Sandblasting operation)		potential	high	high	50 day	high
5	N. Stormont	Community Arena and parking lot	1, 3, 15 and 19	current	high	high	50 day	high
6	N. Stormont	Fuel outlets (former gas station at corner of John St. and CR12)	9	Historical	high	high	50 day	high
7	N. Stormont	Railway track to north		current	high	high	50 day	high
8	N. Stormont	residential and commercial fuel tanks	10, 17 and 20	current	high	high	50 day	high
9	N. Stormont	Medical Centre (southeast corner of George St. and John St.)	8	current	moderate	high	50 day	high
10	N. Stormont	crop fields (to west)	14	current	moderate	high	50 day	high
11	N. Stormont	commercial retail establishments	8	current	low	high	50 day	high
12	N. Stormont	Fuel outlets (north side of Hwy 43 beside Payne River)		current	high	high	2 year	high
13	N. Stormont	Fuel and chemical outlet (west side of CR12, north of railway tracks)		current	high	high	2 year	high
14	N. Stormont	residential and commercial fuel tanks	10, 17 and 20	current	high	high	2 year	high
15	N. Stormont	abandoned railway line (northeast corner of Village)		Historical	high	high	2 year	high
16	N. Stormont	Industrial Zoned land (north of railway tracks, northwest corner of Village)		potential	high	high	2 year	high
17	N. Stormont	funeral home (northeast corner of William St. and Hwy 43)	13	current	moderate	high	2 year	high
18	N. Stormont	farm operation (across hwy 43 from funeral home)		current	moderate	high	2 year	high
19	N. Stormont	crop fields		current	moderate	high	2 year	high
20	N. Stormont	commercial retail establishments (along west side of CR12 north of Hwy 43)	11 and 12	current	low	high	2 year	high
21	N. Stormont	Industrial Zoned land (south of village on east side of CR 12)		current/potential	high	moderate	10 year	moderate
22	N. Stormont	mineral extraction operation		current	moderate	high	10 year	high
23	N. Stormont	farm operation		current	moderate	high/moderate	10 year	high/moderate
24	N. Stormont	crop fields		current	moderate	high/moderate	10 year	high/moderate
25	N. Stormont	mineral extraction operation		current/potential	moderate	moderate	25 year	low
26	N. Stormont	farm operation		current	moderate	moderate	25 year	low
27	N. Stormont	crop fields		current	moderate	moderate	25 year	low
28	N. Stormont	Former Landfill site		Historical	high	high	>25 year	low
29	N. Stormont	abandoned railway line		Historical	high	high/moderate	>25 year	low
30	N. Stormont	Industrial Zoned land		current/potential	high	high/moderate	>25 year	low
31	N. Stormont	mineral extraction operation		current/potential	moderate	high	>25 year	low
32	N. Stormont	farm operation		current	moderate	high/moderate	>25 years	low
33	N. Stormont	crop fields		current	moderate	high/moderate	>25 years	low
34	N. Stormont	commercial retail establishments		current/potential	low	high	>25 years	low

Notes:   Denotes land use risk rating determined by EOWRC Study  
  Denotes contaminant source located outside the 25-year Well Head Protection Area



### **0-50 Day WHPA**

There are eleven potential contaminant sources within the inner WHPA. There is a potential risk of impact to groundwater within this zone. The potential contaminant source facilities include: the welding shop with chemical and fuel storage, former foam insulation manufacturing operation presently operating as a sandblasting operation, land zoned for industrial use, the CP railway line, the community centre/arena building and parking lot, the medical centre, a former commercial fuel outlet on the corner of John street and CR12, commercial operations along CR12 and cropland to the west. As well, there are several domestic above ground fuel storage tanks (ASTs) along John Street, George Street and William Street. All ASTs as well as the potential contaminant source facilities are rated as high hazard potential contaminant sources. The medical centre and cropland are rated as moderate contaminant sources based on the rating scheme offered in the EOWRC report.

### **50 day to 2 Year WHPA**

The second WHPA (50 day to 2 year TOT) extends from the 50 day boundary approximately 775 metres to the north, west and south from the Finch Well Site and approximately 635 metres northeast up to the Payne River. This area includes nine (9) potential contaminant sources including fuel outlets on HWY 43 on the west bank of the Payne River, existing fuel outlet and pesticide storage facility on CR12 just north of the CP railway, abandoned railway lines just east of the village, municipally zoned industrial land north of the CP railway line, a funeral home to the south, a farm located on the south side of HWY 43 just west of William Street intersection, cropland surrounding the Village and commercial establishments along HWY 43 and CR12. As well, several domestic and commercial above ground fuel storage tanks (ASTs) along most residential streets south and east of the Finch Well Site are a potential concern. All ASTs as well as the potential contaminant source facilities are rated as high hazard potential contaminant sources. The funeral home, farm operation and cropland are rated as moderate contaminant sources, while the retail commercial establishments have low potential for contamination.

## **2-10 Year WHPA**

The third WHPA (2 year to 10 year TOT) extends to the south along CR12 to approximately 400 m beyond the Hunter's Road/Waldroff Road intersection. This WHPA also extends approximately 900 m southeast from this intersection. The boundary of this area also extends approximately 475 to 965 m east and west respectively of CR12. Within the 2 to 10 year WHPA there are a few farm operations along CR12 and plenty of cropland. There is also an area of land zoned for industrial land use located approximately 235 metres south of the northern boundary inside this WHPA zone. By extending the capture area to the west of CR12, this includes a mineral aggregate extraction operation on Conc.1/2 Rd. This area represents a greater travel time within the WHPA but the GwIS index values remain high due to an increase in overburden hydraulic conductivity within the buried esker complex at depth in this WHPA. Altogether there are four (4) sources of contamination within this protection area. The industrial area has a high potential for contamination while the remaining sources provide a moderate rating.

## **10-25 Year WHPA**

The fourth WHPA (10 year to 25 year TOT) extends further south along CR12 to the Sandtown Road, a distance of approximately 950 metres beyond the 10 year TOT boundary. The WHPA eastern and western boundaries extend approximately 600 metres and 950 metres respectively on either side of CR12. There were three (3) potential contaminant sources, rated moderate, identified within this zone. Farm operations and cropland are common and an area of land zoned for mineral extraction in the most southeasterly area and a property operating as a pit and/or quarry in the north-western section of this WHPA. This area represents a greater travel time within the WHPA; however the GwIS index value remains high according to the regional study (EOWRC report, 2003).

## **Greater than 25 year**

There are seven (7) potential point sources of contamination surrounding the WHPA delineated for the study area, these are; a former landfill site to the southwest, an abandoned railway line to the east, land zoned for industrial use to the west and south,

mineral extraction operations to the west, farm operations and commercial retail establishments. The area is extensively farmed and crop fields are established in the general area. This area is outside the context of this study.

### 3.3.1 LAND-USE RISK RATING

To evaluate all of the data collected during this study in terms of planning for the future, and managing present land development, a matrix system was used to integrate the results of the GwIS index and the WHPA analysis. The MOE rating scheme recommended in the *MOE Terms of Reference* was used and is presented in Table 3 below:

**Table 3: Land Use Risk Rating Matrix**

Saturated Zone Time of Travel	Groundwater Intrinsic Susceptibility (GwIS) Index		
	< 30	30 to 80	> 80
<50 day	High	High	High
50 day to 2 years	High	High	High/Moderate
2 to 10 years	High	Moderate	Low
10 to 25 years	Moderate	Low	Low

Based on the matrix shown above all of the area falling within the 0 to 2 year WHPA should be considered high risk as well as a portion of the 10-year and 25-year WHPAs. This is primarily due to the fact that the unstructured nature and thickness of the overburden materials (gravel till) provides little natural protection from potential contamination sources. A remaining section of the 10-year WHPA should be considered medium risk. This is primarily due to an increase in the thickness of overburden in this area. The remaining sections of the 25-year WHPA should be considered low risk. This is primarily due to the increase in travel time, increased thickness of overburden and the potential for remediation over this distance. The Land-Use Risk Rating (LURR) for Finch is shown in Figure 4.

### **3.4 GROUNDWATER SOURCE PROTECTION PLAN**

The following describes elements of a groundwater source protection plan to assist the municipality in protecting this resource, given the high reliance on groundwater as a potable water supply.

#### **3.4.1 Elements of the Groundwater Source Protection Action Plan**

The objective of a groundwater source protection action plan is to identify areas of greatest concern with respect to safe guarding the quality of a groundwater resource.

The goal is to ensure a balance between the benefits of groundwater protection and potential impacts on economic and community development. Generally more stringent controls would be required close to the municipal well field, as well as in areas of greater sensitivity (lower GwIS).

##### **3.4.1.1 Risk Management Strategies**

To reduce risk within the WHPA a number of approaches can be applied. In general the most beneficial approach is *risk avoidance*, followed by *risk management* and *awareness*. These three approaches are very different with regards to implementation.

Risk avoidance requires the removal of risk. In the context of municipal well head protection, this would be achieved by removing from the area those potential sources that are of greatest risk of causing an adverse impact to the underlying groundwater. Of the three strategies, risk avoidance is generally considered to be the most problematic to implement (methods of implementation are discussed in the Section 3.4.2.1).

*Risk management* would not be as effective because the potential source of contamination would remain at its current location; however stringent programs would be implemented to manage risks on the property and if implemented properly are very effective.

The third strategy is *awareness*. By informing people that they are located near the municipal groundwater wells and instructing them of the potential hazards of adversely impacting the groundwater, there will be an increased level of interest to implement risk management practices.

#### **3.4.1.2 Risk Ranking & Associated Risk Management Strategies**

These three strategies, risk avoidance, risk management and awareness, as described above, provide different levels of protection and require different levels of effort to implement. A ranking system is therefore required to identify which level of effort is required. As described in Section 3.3.1 of this report, a Land-Use Risk Rating has been assigned within the WHPAs. The Land-Use Risk Rating takes into account time of travel to the well, intrinsic susceptibility, and the type of land-use activities. Due to the natural geology of the area (in places overburden <3 m) the WHPA's were rated high and moderate depending on the *thickness of overburden material* factor and distance from the Well Site (Figure 4).

As defined in the MOE *Terms of Reference* there were three designations for Land-use Risk Rating derived from an estimate of time of travel and intrinsic susceptibility. In the zone rated High for Land-Use Risk Rating, the objective should be one of risk avoidance. It is within this zone that the greatest care should be taken to manage any current chemical use and handling practices and to minimize, or even avoid, the addition of moderate to high risk sources. In the zone rated Moderate for Land-Use Risk Rating, the objective should be one of risk avoidance where possible and risk management. Within the areas rated low with respect to Land-use Risk Rating, the emphasis should be on awareness and education as a minimum.

#### **3.4.2 Implementation of Well Head Protection Strategy**

The suggested strategies presented above identify different activities to be implemented within different Land-Use Risk Rating zones. The implementation of any of these strategies depends on whether the site is a Greenfield site (as yet undeveloped) or a site that is already developed. In the case of a Greenfield site, requirements can much

more easily be imposed during the planning stages prior to someone purchasing or developing the property. In the case where the property is currently developed, it is much more difficult to impose requirements.

### **3.4.2.1 Risk Avoidance**

In the High and Moderate risk ranked area the greatest care should be taken to manage any current chemical use and handling practices and to minimize, or even avoid, the addition of moderate to high risk sources (For example: landfill sites, sewage lagoons, gas stations, or manufacturing facilities using significant quantities of chemicals). Moderate risk sources could include smaller manufacturing facilities or any operation that handles a moderate quantity of chemicals on a regular basis.

In Section 5.7 of the EOWRC report and Appendix D of this report, a ranking system was developed to evaluate potential contaminant sources. This ranking system, or one similar, could be used to define which businesses should be excluded from establishing themselves within a High or Moderate Land-Use Risk Rating area.

To implement risk avoidance, Greenfield sites should be zoned such that certain activities are not permitted. In the Village of Finch, industries are already present within the WHPA, and forcing a change of land-use may be difficult. A method that is being considered by municipalities in Ontario is regulation through land-use planning. It is possible to amend the Official Plan and By-laws to restrict the type of land-uses in WHPA's with restrictions being more stringent closer to the well head itself. This is relatively straightforward for "Greenfield" land but is more problematic for properties that are already developed.

It should be noted that under the current Planning Code in Ontario, even though some municipalities in Ontario are thinking of developing similar chemical restriction by-laws, it is possible that they may not be legal if challenged in the court or at an OMB hearing.

For the Village of Finch, changing current zoning of Greenfield sites to limit development of high and moderate risk contaminant sources should be considered for those areas ranked High and Moderate in the Land-Use Risk Rating. The proposed industrial park, planned just south of the Village on the east side of CR12 is one such

property that the Township planner should consider risk avoidance strategy. The current zoning by-law for areas outside the Village of Finch is shown in Appendix E. The zoning map for the Village is pending. For the Reader's interest, other risk avoidance measures used by other municipalities in Ontario are discussed in Appendix F.

In Summary the tasks Associated with Risk Avoidance are the Following:

- Task 1: Develop a ranking system to evaluate potential contaminant sources – and use this to define which businesses in the future should be excluded from establishing themselves within a High or Moderate Land-Use Risk Rating area.
- Task 2: Through land-use planning, change zoning such that certain activities are not permitted. This includes amending the Official Plan and creating By-laws to restrict the type of land-uses in WHPA's with restrictions being more stringent closer to the well head itself.

#### **3.4.2.2 Risk Management**

Where high or moderate risk activities are already present in a high or moderate risk area, initiatives need to be put in place to discourage expansion, and/or require best management practices.

##### **Discouraging Expansion:**

In cases where there are existing industries and it is too difficult or costly to move them out of the WHPA, or in cases where a new development is desired, a permitting program could be implemented requiring approval before any new expansion/development is undertaken. The permitting program would include agreements placing restrictions on the types and quantities of chemicals used, and activities undertaken based on their potential to impact the groundwater. Any future expansion/development within the WHPA, should be accompanied by a requirement to implement best management practices as described below. Permitting would serve to monitor and direct expansion/development and can also include implementation of land securement, or protection mechanisms.

## **Implementing Best Management Practices**

Best Management Practices (BMPs) identify specific actions that lead to pollution prevention. Many of the practices are simple to implement and relatively inexpensive. It should be noted that the clean-up of any spill is extremely costly and therefore the implementation of best management practices is generally inexpensive insurance for the property owner.

To ensure the implementation of Best Management Practices, the Municipality could also encourage/ require the implementation of the following for businesses through by-law creation:

- a recognized environmental management system (such as ISO14001)
- pollution prevention plans;
- spill response plans;
- Completion and submittal of a yearly report summarizing the amount and type of chemicals in use and handling/spill response practices. (Criteria would have to be developed for minimum quantities and types of chemicals that required reporting). The questionnaire included with the MOE TOR (Appendix G) could be used for this purpose. This should include a chemical inventory, and interviews with operational staff.
- A monitoring network is recommended to be established within the village targeting various chemical parameters based on local business activities.
- Impose restrictions to quantities of chemicals stored on-site, or restrict increases in the use of chemicals on site.
- The municipality could strongly encourage all medium and high risk contaminant sources to attend a workshop for BMP implementation.

By having such systems in place, it would ensure that the Best Management Practices are being implemented on a continual basis. Sample BMP fact sheets, developed by the Region of Waterloo, could be used as templates for 31 of the business sectors identified in the Finch study area. These are provided in Appendix G of this report.



To ensure the implementation of Best Management Practices, the Municipality could also encourage the implementation of the following for residents through creation of a task force (volunteer or otherwise). A general invitation should be extended by the Township for applicants to apply for a position on the task force (via local papers and/or website). Selected members of the task force should include representatives from all stakeholder groups (private business, general public, local interest groups, government, etc.) in order to ensure an effective committee:

- Verify the existence, construction and use of private water wells. Adequately constructed potable water wells with established integrity and still in existence within the 10, 2 year and 50 day TOT should be evaluated for inclusion in the monitoring program. All other wells should be properly abandoned beginning in the high risk ranked areas of the WHPP. Consideration can be given to properly grouting proposed observation wells, by over drilling the existing casing.
- Verification of the proper decommissioning of private septic systems is strongly recommended beginning in the high risk ranked areas. A program should be undertaken to ensure all tanks have been properly emptied and abandoned, and septic fields decommissioned.
- WESA noted that many residents have heating oil tanks on their property. Provision of best management practices for these tanks would be beneficial. Best management practices should include information with respect to regular inspection of tanks for leaks, tank replacement requirements and spill/leak protection and response/notification in compliance with Ontario Regulation 213/01.
- Provision of best management practices for storing and handling household hazardous chemicals would be beneficial, this can expand to include household cleaners, paints, solvents, batteries, pesticides and fertilizers. In general, household use of pesticides should be discouraged and information on more environmental pest management practices provided and encouraged. Consideration to designating a day and drop off location for household hazardous wastes at a cost per item for the user is recommended.

Based on the Land-Use Risk Rating results for the Village of Finch, risk management will likely represent the primary method of Well Head Protection. It is recommended that all medium and high risk contaminant sources be targeted for the implementation of risk management measures.

In Summary the tasks Associated with Risk Management are the Following:

**Task 1:** Develop a permitting program to be implemented requiring approval before any new expansion/development is undertaken. Include placing restrictions on the types and quantities of chemicals used, and activities undertaken based on their potential to impact the groundwater.

**Task 2:** encourage the implementation of best management practices for businesses within the WHPA through By-law creation.

**Task 3:** encourage the implementation of best management practices for residents through creation of a task force, and programs for implementation.

#### **3.4.2.3 Awareness (Education and Training)**

The objective of any awareness campaign is to target an audience, and inform as many of the target audience as possible. In this case, the targeted audience is everyone within the WHPA. It should be noted that people residing/working outside the WHPA would also benefit from this training.

There are various methods used to inform the target audience. Given the technical nature of the topic, it is strongly suggested that the material be presented in an interactive manner. Workshops are a very effective educational tool that can reach a large number of businesses at one time. For example, a one-day workshop could be held for up to 50 attendees to present the concepts of groundwater protection, to introduce the concepts of risk management in terms of environmental impact, and to present some Best Management Practices. The workshop would explain how they could potentially impact the groundwater and what measures need to be taken to prevent this from occurring.

Materials to be presented in the workshop could include the BMPs included in Appendix G. Some appropriate BMPs should be presented and reviewed in detail to demonstrate their applicability and usefulness. Implementation of such BMPs should be discussed so that participants have a concrete notion of the steps required to implement the components of the BMP. And to ensure continued awareness and implementation of the BMPs, the workshop could also mention the use of Environmental Management Systems, Pollution Prevention Plans and Spill Response Plans. The workshop should provide a list of references and web sites that participants could consult to develop their own plans.

To reach a broader audience, mail-outs included with municipal correspondence can be an effective means of raising awareness. As well public signage indicating the boundaries of the WHPA on major access routes to the Village of Finch could be established. Topics of the material included in mail outs could include the following:

- General information regarding the importance of protecting their groundwater resources
- A summary of the results of groundwater study including illustrations showing the location of the municipal wells and the groundwater capture areas
- General information about potential contaminants and how these could impact the groundwater (spills along the road, spills from underground storage tanks, impact from overuse of fertilizers and pesticides).
- Suggestions regarding prevention of potential groundwater impacts (specifically targeted to people with fuel storage tanks)
- What actions one should take in the event of a spill (reporting, cleaning-up, use of spill kits)

Another approach for creating awareness would be to have environmental theme days at the local schools associated with the WHPP, including ideas such as having students create summaries of chemicals used in the household and household chemical and waste handling practices, discussing environmental alternatives to chemical use, educating students on groundwater protection, have a groundwater protection poster contest, etc. The education program can be targeted to different age groups through age appropriate projects.

In Summary the tasks Associated with Awareness (Education and Training) are the following:

**Task 1:** Identify key activities of concern, and present workshops inviting specific potential polluter groups. Present BMPs, including implementation strategies, cost considerations, where more information can be found, who can help, etc.;

**Task 2:** Create an area on the Township website with key information on the WHPP, contacts and BMPs

**Task 3:** Target potential polluters through mail outs that outline specific BMPs;

**Task 4:** Design and post public signs indicating the boundaries of the WHPA, and the risk ranking of each area;

**Task 5:** Consider implementation of household hazardous waste programs for drop-off on a cost per user basis; and

**Task 6:** Encourage educational initiatives through the school board curriculum focusing specifically on groundwater protection within the Village of Finch.

### **3.4.3 Summary of Action Plan Strategies**

The Well Head Protection Areas in the Village of Finch are ranked High to Low with respect to Land-Use Risk Rating. Within these Land-Use Risk Rating areas, there are potential contaminant sources of low, moderate and high risk. To best manage the groundwater resources the strategies listed in Table 4 are recommended.

**Table 4: Summary of Recommended Well Head Protection Strategy**

<b>WHPP Strategy</b>	<b>Recommended Timeframe for Implementation</b>
<b>Risk Avoidance</b>	
Task 1: Develop a ranking system; define businesses for exclusion from High or Moderate Land-Use Risk Rating area.	Implement as soon as possible
Task 2: Through land-use planning change zoning to restrict future activities within the WHPA.	coordinate timing with the SDG County Plan
<b>Risk Management</b>	
Task 1: Develop a permitting program for expansions/ new developments. Include restrictions on types and quantities of chemicals, activities undertaken, based on potential groundwater impact.	August 2006
<p>Task 2: encourage the implementation of best management practices within the WHPA through a Groundwater Task Force and by-law creation.</p> <p>Task 2a</p> <ul style="list-style-type: none"> <li>encourage all medium and high risk contaminant sources to attend a workshop for BMP implementation</li> </ul> <p>Task 2b</p> <ul style="list-style-type: none"> <li>Provision of best management practices for heating oil tanks (business and residential)</li> <li>Provision of best management practices for storing and handling household hazardous chemicals (business and residential)</li> <li>designate day and drop off location for household hazardous wastes at a cost per item for the user.</li> </ul>	<p>Task 2a Implement as soon as possible</p> <p>Task 2b December 2005</p>

WHPP Strategy	Recommended Timeframe for Implementation
<p><b>Task 2c</b></p> <ul style="list-style-type: none"> <li>• recommend site interviews to complete chemical list and handling and storage inventory for the medium and high risk contaminant sources</li> <li>• based on the information collected one or several the following plans may be developed; <ul style="list-style-type: none"> <li>▫ a recognized environmental management system (such as ISO14001);</li> <li>▫ pollution prevention plans;</li> <li>▫ spill response plans;</li> <li>▫ Yearly chemical use and handling reports.</li> </ul> </li> </ul>	<p><b>Task 2c</b></p> <p>2006 – for all businesses within the 50 day TOT</p> <p>- for all businesses as soon as economically possible and as staffing permits within all other zones beginning with the 2 year TOT zone and working out towards the 25 year WHPA.</p>
<p><b>Task 3: encourage the implementation of best management practices through creation of a task force, and programs for implementation.</b></p> <ul style="list-style-type: none"> <li>• Verify the existence, construction and use of private water wells. Evaluate wells for inclusion in the monitoring program.</li> <li>• Verification and carrying out of the proper decommissioning of private wells and septic systems</li> </ul>	<p>2005 –enhanced inventory within the 50 day TOT</p> <p>2006 – start implementation of abandonment program.</p> <p>–within all other zones starting in the earliest time zone and highest risk land-use areas and working out towards the outer time zones and low risk land-use areas.</p>
<p><b>Awareness (Education and Training)</b></p>	<p>Coordinate all with Management strategy initiatives. Education initiatives should commence immediately and be on-going throughout execution of the WHPP.</p>
<p><b>Task 1: Identify activities of concern, and present BMP workshops inviting specific potential polluter groups.</b></p>	<p>Implement as soon as possible</p>
<p><b>Task 2: Create an area on the Township website with key information on the WHPP, contacts and BMPs.</b></p>	<p>Website creation by end of 2005</p>
<p><b>Task 3: Send mail outs that outline specific BMPs;</b></p>	<p>Coordinate with mail – out activities conducted for other purposes</p>

WHPP Strategy	Recommended Timeframe for Implementation
Task 4: After holding the information workshops, design and post public signs indicating the boundaries of the WHPA, and the risk ranking of each area	Implement as soon as possible.
Task 5: advertise household hazardous waste programs	Coordinate with household hazardous waste initiatives
Task 6: Encourage educational initiatives through the school curriculum	Implement as soon as possible. Encourage teacher and student participation and ideas.

The advantages and disadvantages of each of the methods of implementation, along with a relative cost, are presented in Table 5.

The suggested actions outlined above provide a framework within which stakeholders can provide input and recommendations. Successful implementation requires co-operation from the general population. By starting a dialogue involving participation and input by the public, a more sustainable program will be achieved in the long term. Once the municipality has compiled a list of options regarding implementation of environmental management strategies, these should be presented and discussed with the public to incorporate their comments and ideas. Implementation of any such policies would require input and co-operation from the public.

This strategy is a proposed plan that can be discussed with stakeholders and interested parties. The details of the specific components as well as an implementation schedule should be developed in consultation with these groups.

#### 4.0 RECOMMENDED WATER SUPPLY WELL MONITORING PROGRAM

The components of a recommended Water Supply Well Monitoring Program are presented below. These recommendations were made based on a review of historical Site reports, the regional groundwater study report (EOWRC, October 2003), and site observations. The rationale for specifying each component is also provided.

#### 4.1 REVIEW OF HISTORICAL SITE REPORTS

To complete this portion of the work WESA obtained and reviewed copies of the following reports:

- 'Report on a Groundwater Survey in the Village of Finch', Ontario Water Resources Commission, 1971 (OWRC, 1971);
- 'Village of Finch Water System, Engineer's Report for Water Works', Kostuch Engineering Ltd., March, 2001;
- 'Quarterly Reports on Drinking Water Quality', Ontario Clean Water Agency (OCWA), From October 2000 to March 2003;
- 'Annual Report, Drinking –Water Systems Regulation O. Reg. 170/03', OCWA, January 1 to December 31, 2003.
- 'Water Plant Performance Assessment Reports' for 2001, 2002, 2003 and up to March 2004, OCWA.

From the OWRC, 1971 report the following is noted. A groundwater survey was conducted in March, 1971 to investigate the quality of ground water as a potential municipal supply. A survey conducted in 1970 by the St. Lawrence and Ottawa Valleys Health Unit, indicated that 58 per cent of the drilled wells and 69 per cent of the dug wells yielded water of unsatisfactory bacterial quality. In this study of 12 well samples, 8 had abnormally high concentrations of nitrates, with one exceeding the recommended limit of 10 ppm. The population in 1969 was 409 residents. Shallow wells within the Village had coliform bacteria and abnormally high concentrations of nitrates. The source of these compounds was suspected to be from septic systems. Other wells tested at depths of 110 to 173 feet did not contain bacteria and had low nitrate concentrations. The 1971 report also included information on the location of private water wells. A summary of well construction logs and a figure of well locations are included in Appendix H for the reader's convenience.

From the 2001 engineering report prepared by Kostuch Engineering Limited, a review of 1999, and 2000 microbiological water quality data was undertaken. The reports revealed, that two adverse microbiological samples were observed in the distribution system in 1999, and another two in July of 2000. Raw water quality from 2000 indicated a level of total coliforms detected on two occasions reported at counts of 1



**Table 5**  
**Evaluation of Protection Methods**  
**Village of Finch Well Head Protection Plan Study**

B3018tablesJuly-04.xls

Protection Method	Advantages	Disadvantages	Associated Costs
<b>By-laws, Official Plans Zoning Changes</b>	<ul style="list-style-type: none"> <li>- is legislated and can be enforced</li> <li>- ensures an even playing field</li> <li>- highly effective</li> </ul>	<ul style="list-style-type: none"> <li>- new regulations have to be developed and passed</li> <li>- costs to current businesses perceived to be a deterrent to economic growth</li> <li>- may be legally challenged</li> </ul>	<ul style="list-style-type: none"> <li>- staff time to draft amendments</li> <li>- hiring of additional staff to enforce</li> <li>- legal costs for review of amendments</li> </ul>
<b>Development Agreements</b>	<ul style="list-style-type: none"> <li>- can be legislated but does not have to be</li> <li>- targets specific locations of concern</li> </ul>	<ul style="list-style-type: none"> <li>- increased development costs</li> </ul>	<ul style="list-style-type: none"> <li>- municipal staff time</li> </ul>
<b>Monitoring and Reporting</b>	<ul style="list-style-type: none"> <li>- can be legislated but does not have to be</li> <li>- targets specific locations of concern</li> </ul>	<ul style="list-style-type: none"> <li>- increased operational costs for businesses</li> </ul>	<ul style="list-style-type: none"> <li>- municipal staff time</li> <li>- hiring of additional staff to enforce</li> </ul>
<b>Incentives</b>	<ul style="list-style-type: none"> <li>- more attractive to businesses</li> <li>- raises level of environmental awareness</li> <li>- reduces risks and liabilities for businesses</li> <li>- long term cost savings</li> <li>- business anonymity</li> </ul>	<ul style="list-style-type: none"> <li>- voluntary rather than required</li> <li>- program has to be "sold" to the business community</li> <li>- may not capture businesses with the highest risk</li> </ul>	<ul style="list-style-type: none"> <li>- varied but example of \$18,000 per site for BWQP (see Appendix F).</li> </ul>
<b>Education and Training</b>	<ul style="list-style-type: none"> <li>- raises level of environmental awareness</li> <li>- reduces risks and liabilities for businesses</li> <li>- long term cost savings</li> </ul>	<ul style="list-style-type: none"> <li>- voluntary rather than required</li> <li>- requires management support at each business</li> <li>- more difficult to monitor success</li> </ul>	<ul style="list-style-type: none"> <li>- \$2000 to \$5000 per event or facility</li> </ul>

and 9 per 100 ml. Within this report it is noted that a sanitary sewer system had recently been constructed in the Village. Information in the report suggested that the wells were protected from agricultural runoff, and that the recent addition of the sanitary sewer system would act to help protect the wells from septic systems as a source of contamination. Raw water sampling was conducted in the spring of 2001. Nitrate and nitrite results were reported as non-detect, however nitrogen was reported slightly above the MOE operational guideline. The report outlined a concern that the nitrogen levels could be a result of septic or sewage effluent contamination. Levels of aluminium and copper were also noted, again only exceeding operational or aesthetic guidelines. The aluminium was speculated to originate from alumino-silicate clay, and the copper was felt to be a potentially erroneous result due to its unusualness, though verification sampling was recommended.

From the OCWA quarterly and annual reports, the following observations were noted with respect to Raw water quality:

- copper was detected in the water supply in a September 18, 2000 and January 1, 2003 monitoring event at 0.013 mg/L and 0.033 mg/L respectively. These results are well below the 1 mg/L Aesthetic Objective, however demonstrate that the copper identified previously was likely not an erroneous result;
- raw water quality turbidity ranged higher than 1 NTU in the January to March 2001 and October to December, 2002 reporting periods.
- Levels of bromodichloromethane, bromoform, chloroform and dibromochloromethane have generally been detected. These are the most commonly detected trihalomethanes. Trihalomethanes have consistently been reported in the treated and distribution water, though have met the required Maximum Acceptable Concentration (MAC);
- Nitrates have been detected in three sampling events (April 24, 2001, October 24, 2001, January 20, 2003) at concentrations of 0.11, 0.14 and 0.11 mg/L respectively, (well below the MAC of 10 mg/L).

- Raw water bacteriological adverse results with respect to total coliforms, were reported as per the below. Frequent reporting of higher than 200 counts of background colonies, especially at the location of MW2 (in 2003), were also reported, however have not been reproduced in the following table.

**Table 6: Summary of Reported Total Coliform Raw Water Quality**

<b>Date</b>	<b>Raw Water Adverse Reports (Total Coliforms)</b>	<b>Total coliform count (per 100 ml)</b>
March, 2000	1	1
April, 2000	1	1
November, 2000	1	9
April, 2002	1	1
May, 2003	1	1
June, 2003	1	1
November, 2003	2	2,3
December, 2003	3	2,5,12
March, 2004	2	1,1
April, 2004	1	20

For information purposes, excerpts for the above reported parameters have been reproduced below from the Technical Support Document for Ontario Drinking Water Standards, Objectives and Guidelines, published by the Ontario Ministry of the Environment in June, 2003. A more detailed evaluation and analysis has been prepared for the Township's review as a memorandum under separate cover, dated July 13, 2004 and entitled "Township of Finch Historical Raw Water Quality – Review and Recommendations".

- "Aluminum in untreated water is present in the form of very fine particles of alumino-silicate clay. These clay particles are effectively removed in coagulation/filtration."

- “The aesthetic objective for copper in drinking water is 1.0 mg/L. Copper occurs naturally in the environment but is rarely present in raw water.” It is therefore unusual that copper has been consistently detected at low levels in the Finch raw water supply, though is not considered a health concern. Please note: “copper is used extensively in domestic plumbing in tubing and fittings and is an essential trace component in food. Drinking water has the potential to be corrosive and to cause copper to dissolve in water. At levels above 1.0 mg/L, copper may impart an objectionable taste to the water. Although the intake of large doses of copper has resulted in adverse health effects such as stomach upsets, the levels at which this occurs are much higher than the aesthetic objective.”
- “The maximum acceptable concentration of nitrates in drinking water is 10 mg/L as nitrogen. Nitrates are present in water (particularly ground water) as a result of decay of plant or animal material, the use of agricultural fertilizers, domestic sewage or treated wastewater contamination, or geological formations containing soluble nitrogen compounds.”
- “The coliform group of bacteria has been the most commonly used indicator of water quality. The coliform group consists of all aerobic and facultatively anaerobic, gram-negative, oxidasenegative, non-spore forming, rod-shaped bacteria that ferment lactose in a broth medium with gas formation within 48 hours at 35°C. The group generally comprises the genera *Escherichia*, *Klebsiella*, *Enterobacter* and *Citrobacter*. The presence of these bacteria in drinking water is indicative of inadequate filtration/disinfection or in the distribution system a continuing loss of the chlorine residual. MPN (Most Probable Number), MF and P/A are methods that may be used to detect and measure coliform populations in drinking water. The tests have slightly different sensitivities to the various bacteria. Occasionally samples will produce positive results in one test and not with the others. In all cases where discrepancies are found, results from the method producing the positive result will be used in assessing the water quality.”

- “The maximum acceptable concentration (MAC) for trihalomethanes (THMs) in drinking water is 0.10 mg/L based on a four quarter moving annual average of test results. Trihalomethanes are the most widely occurring synthetic organics found in chlorinated drinking water. The four most commonly detected trihalomethanes in drinking water are chloroform, bromodichloromethane, chlorodibromomethane and bromoform. Primarily, trihalomethanes in drinking water are produced by the reaction of chlorine and the naturally occurring organics (precursors) left in the water after filtration.”  
“Control of turbidity in drinking-water systems is important for both health and aesthetic reasons. The substances and particles that cause turbidity can be responsible for significant interference with disinfection, can be a source of disease-causing organisms and can shield pathogenic organisms from the disinfection process. Turbidity is an important indicator of treatment efficiency and the efficiency of filters in particular. The effect of turbidity on disinfection efficiency, including potential for disinfection byproducts, is related to the type and nature of the particles in the water. A raw water supply which is surface water or ground water under direct influence of surface water is likely to contain organic particles that cause turbidity and adversely affect disinfection efficiency. A significant factor in the formation of disinfection by-products is the organic or humic component of turbidity. Raw water supply which is ground water with very low organic content may contain inorganic based turbidity, which may not seriously hinder disinfection. For such waters, an Operational Guideline for turbidity is not established. Since ground water quality is inherently stable, any significant variation in turbidity, excluding pump startup, should be investigated and analyzed immediately for the potential of surface water influence and the presence of organic particles. Turbidity in excess of 5.0 NTU becomes visible to the naked eye and as such a majority of consumers may object to its presence. Therefore, an aesthetic objective of 5.0 NTU has been set for all waters at the point of consumption.”

## 4.2 GROUNDWATER QUALITY MONITORING PROGRAM

➤ Quarterly 'raw water' sampling program for Municipal wells

1. Raw water chemistry analysis should be performed for the Municipal wells. The following chemistry data is recommended to be tabulated and maintained within a suitable database for assessment of long term water quality trends on a quarterly basis. This list of parameters is additional to the O. Reg. 170/03 requirements and includes:

- Iron
- Manganese
- Hardness
- Alkalinity
- pH
- Conductivity
- Sodium
- Ammonia
- Chloride
- Colour
- Calcium
- Magnesium
- Dissolved Organic Carbon
- Sulphate
- Total Dissolved Solids

2. Manual collection of static water levels from the Municipal wells and the observation wells (including potentially the Community Centre/Arena well on Figure 1) in conjunction with the quarterly sampling event. To be representative of static aquifer conditions the data should be collected a minimum of 24 hours after the last operation of any site wells.

*Rationale: A long term monitoring program would serve to assess the seasonal variations and long term water quality trends, and any effects from over-pumping (i.e. from the potential up-welling of poor groundwater quality at depth during periods of low aquifer recharge).*

*Please note:*

*Given the high density Site location, the presence of commercial/industrial land use, and the 'high' aquifer intrinsic susceptibility index, the greatest potential sources of groundwater quality degradation are industrial land use and fuel storage impacts derived from lands to the north, northwest, east and southeast. It is duly noted that chemical parameter testing at the municipal wells is already being completed as part of the compliance requirements of O. Reg. 170/03, and that this testing is quite costly. The frequency of testing outlined in O. Reg. 170/03 has been established by the MOE for health related groundwater quality monitoring purposes. This monitoring at the wellhead however is not preventative in nature, and will serve to create awareness of a problem once the impact has been created. Additionally, a preventative monitoring program is recommended as outlined in the following paragraph.*

*To monitor for chemical impacts on adjacent properties within the WHPA, it is proposed that the monitoring of non-municipal activities be passed on to the commercial/industrial establishments of concern to the largest extent possible. This can only be made mandatory for new establishments or establishments requesting an expansion, as part of the recommended By-law permitting program. For established Industrial/commercial establishments in the high risk ranked zone of the WHPA, the approach will be risk management and awareness. Established businesses should be encouraged to report their chemical use and handling practices and any concerns based on historical and present day activities. Reporting procedures for any adverse impacts to the groundwater table would follow the procedures established by the MOE, and include new procedures, where possible, for reporting to a designated qualified group for well head protection within the Township. Analytical results should be compared to potable MOE criteria as appropriate. In addition, educating residents on best management practices for handling of household chemicals, proper care of heating storage tanks, and spill prevention and reporting will greatly assist in the groundwater protection program.*

➤ **Bi-annual Assessment and Reporting of Raw Water Quality Trends**

1. Every 2 years a brief letter report should be prepared by a qualified Hydrogeologist assessing any apparent changes/trends in raw water quality and well static water level elevations. The assessment should evaluate both the quarterly groundwater quality data outlined above and the weekly microbiological quality data collected by the Operator.

*Rationale: To be of value, the raw water quality data should be assessed for trends on a regular basis in order to identify any existing or potential future concerns. The 'Engineer's Report' that is completed every five years may not be able to identify/mitigate groundwater quality issues in a prompt enough manner.*

#### **4.3 WELL INSPECTION PROGRAM**

➤ **Semi-Annual General Inspection of Municipal Wells**

The following inspections and tasks should be undertaken at each well on a semi-annual basis at approximately the same dates each year, preferably in the spring and fall:

1. Inspect the well vent to ensure that it is not blocked, that the screen is secure, and that the opening is shielded.
2. Visually inspect casing wall, cap and cover for cracks or other damage.
3. Visually inspect casing for signs of any movement.
4. Review the water level and compare with previous measurements. Observe levels after pumps have been off for a minimum period.
5. Review the flow and pressure readings as an indication of pump operation, and compare with previous measurements.
6. Review the well field protection plan for any changes or modifications to the local site condition.
7. Ensure that the well record and Permit to Take Water are valid and available for inspection.



- Every five years re-assess well and pump performance
  1. A step-drawdown test should be conducted for each well in a manner that may be repeated in the future for evaluation and comparison of well specific capacity (yield/increment of drawdown) and pump performance (amperage draw and pumping capacity). The program will use existing flow meters, pumps, and pressure gauges and will not involve pump shut down or well recovery between steps.
- Every ten years remove and inspect the pumps and assess the condition of the well.
  1. Remove well pump and inspect/repair pump, casing and pitless adaptor.
  2. Undertake a camera inspection of the well and assess the need for cleaning (i.e. acid treatment) and/or well re-development.

*Rationale: The well inspection program is necessary to ensure that the site wells are maintained in optimum condition to prevent the potential local entry of microbial contamination at the well casing and/or the direct entry of foreign material.*

## 5.0 CONCLUSIONS

Based on the information provided to WESA, and the complementary information and data collected in the field and from additional studies and reports, WESA has utilized the Well Head Protection Areas (WHPA) for the Municipality of North Stormont, Village of Finch water supply defined by the 2003 EOWRC report, and expanded the boundaries in areas of known high to moderate risk activities for a more conservative approach to well head protection, knowing the uncertainties inherent in the modeling process, and based on concerns that the 'high' intrinsic aquifer susceptibility of the entire Finch study area should be protected. The following conclusions were derived during the course of this study.

- The regional geology of the Village of Finch is comprised unconsolidated deposits consisting primarily of a till plain with minor sand and gravel overlying the limestone bedrock of the Verulam Formation. Within the immediate vicinity of the Village of Finch, the bedrock is encountered at varying depths ranging from 3.3 m to 6.4m below the surface. The overburden materials are comprised of plain till deposits underlain by silt and clay rich gravel deposits. The local aquifer is located within the overburden and weathered bedrock Contact Zone. The municipal wells receive groundwater from 16 metres (53 feet) to 43 metres (140 feet) below the limestone bedrock surface.
- Due to the natural geologic conditions within the study area the Groundwater Intrinsic Susceptibility (GwSI) index determined by the EOWRC report to vary from high to moderate. The GwSI is calculated based on the natural conditions (i.e. thickness) of the geologic materials found above the groundwater aquifer. In this case, the overlying sediments are of moderate permeability, offering very little natural protection from potential contamination.
- An inventory of potential contaminant sources was completed initially by Robinson Consultant Inc. et al. for the EOWRC report (October 2003) and augmented by WESA during a recent field visit. Thirty-four potential sources were identified. Twenty-seven sources fall within the Well Head Protection Areas.
- Each of the potential sources was rated to assign a value corresponding to potential risk of impact. Those sources that were classified as a potentially high risk for contamination included the landfill, large lagoons for manure, gasoline service stations (past and present), domestic above groundwater fuel storage tanks, and industries. Those sources that classified as a medium risk generally included establishments with smaller quantities of chemicals on site such as commercial establishments with chemical storage, funeral home, medical centre, mineral extraction operations, crop fields (land application of biosolids or septage) and small farm operations.

- A Land-Use Risk Rating method was used to evaluate the overall risk to the underlying aquifers. Due to the limited depth and nature of the overburden deposits, the Land-Use Risk Rating was high within the 50 day, 2 year and north-western part of the 10-year and 25-year WHPAs. A south-eastern section of the 10 year WHPA was rated as moderate and within the south-eastern extent of the 25-year WHPA the land-use risk rating was low.
- To ensure long-term integrity of the groundwater, it is important that proper land stewardship be implemented. Any Greenfield sites remaining within the high Land-Use Risk Rating areas should be zoned to limit high or moderate risk sources. Given the current legislative and political climate the protective actions recommended in the report, especially with respect to the 50 day and 2 year WHPA's should be strongly adopted by the Township with regards to by-law enforcement and compliance inspections. This also applies to all environmental management measures for all potential sources of contamination rated high or moderate. As the very minimum, awareness and education should be provided to all potential sources of contamination within the WHPA.
- Based on the results presented in this study, the municipality should now move forward to implement a groundwater source protection action plan.
- An outline of historical raw water quality from available reports was included with excerpts from the Technical Support Document for Ontario Drinking Water Standards, Objectives and Guidelines, published by the Ontario Ministry of the Environment in June, 2003. A more detailed evaluation and analysis has been prepared for the Township's review as a memorandum under separate cover, dated July 13, 2004 and entitled "Township of Finch Historical Raw Water Quality – Review and Recommendations".
- A groundwater monitoring program and well inspection program has been provided and should be established in accordance with the recommended schedule.

## 6.0 RECOMMENDATIONS

The objective of this study was to provide a framework for the Township of North Stormont to ensure protection of their Village of Finch groundwater resources. It is important the following recommendations be implemented to promote awareness of groundwater protection, and to implement programs that will ensure long-term protection of this resource.

- 1) It is recommended that the well head protection strategies of risk avoidance, risk management and awareness be implemented as per the tasks and schedule outlined in Table 4 of Section 3.4.4 of this report. A practical and chronological approach to the Finch Municipal Well Head Protection Plan is provided below;
  - a) General planning tasks to be completed in consultation with Council and Planning Department at the Municipality's prudence.
    - i) Establish a groundwater task force to manage all details of the wellhead protection plan. Selected members of the task force should include representatives from all stakeholder groups (private business, general public, local interest groups, government, etc.) in order to ensure an effective committee.
    - ii) Encourage all medium and high risk contaminant sources identified in Table 2 to attend information workshops regarding BMP implementation as soon as possible.
    - iii) Create an area on the municipal website with key information on the WHPP, contacts and BMPs before the end of 2005.
    - iv) Design and post public signs indicating the boundaries of the WHPAs and the Land-use Risk Rating within each WHPA before as soon as possible.
    - v) Define, as soon as possible, future businesses/operations that may be excluded from the high land-use risk rating areas (Figure 4).
    - vi) Through land use planning modify zoning to restrict activities within the WHPA in conjunction with the SDG County Official Plan amendment process.
    - vii) Develop a permitting program for expansions/ new developments. This could include restrictions on types and quantities of chemicals, activities undertaken, based on potential groundwater impact.


- viii) Distribute site specific BMPs by mail to potential high and medium risk sites within all WHPAs.
  - ix) Encourage WHPP educational initiatives through local schools.
  - x) Designate a household hazardous waste depot day in the community, if one does not already exist.
  - xi) As soon as possible the Township is to establish that all fuel oil suppliers for the Village of Finch and outlining high density areas are inspecting all tanks and verifying that the tanks are in proper condition (integrity of tank and containment apparatus), have known and approved construction dates and are properly being maintained before filling is conducted.
- b) It is recommended the following tasks be completed within the 50-day WHPA before the end of 2005;
- i) Verify the existence, construction and use of all water supply wells. Geo-reference all well locations where possible.
  - ii) Establish an overburden and bedrock groundwater monitoring network. Geo-reference all well locations where possible.
  - iii) Distribute and encourage the completion of the Commercial Contaminant Use Inventory/Questionnaire to all commercial/industrial establishments within Table 2 (voluntary unless triggered by a by-law - i.e. through expansion).
  - iv) Encourage the implementation of best management practices (BMP) for residences, commercial establishments and industrial properties.
  - v) Verify that all private septic systems have been decommissioned properly.
  - vi) Assess the existence, condition and containment of all AST and UST heating and fuelling tanks (both commercial and domestic). Geo-reference tank locations where possible.
  - vii) Inform people of the requirements to maintain heating/fuelling tanks (Liquid Fuels Handling Act, 2001 and Ont. Reg. 213/01).
- c) It is recommended the following tasks be completed within the 50-day WHPA before the end of 2006;
- i) Abandon all wells not in use as required by the regulations and at the discretion of Municipal Council, re-condition wells in use to current MOE standards.
  - ii) Properly abandon any remaining private septic systems.


- d) It is recommended the following tasks be completed as soon as possible after the 50-day zone is completed within the 2-year WHPA;
- i) Verify the existence, construction and use of all water supply wells. Geo-reference all well locations where possible.
  - ii) Abandon all wells not in use as required by the regulations and at the discretion of Municipal Council, re-condition wells in use to current MOE standards.
  - iii) Establish an overburden and bedrock groundwater monitoring network. Geo-reference all well locations where possible.
  - iv) Distribute and encourage the completion of the Commercial Contaminant Use Inventory/Questionnaire to all commercial/industrial establishments within Table 2 (voluntary unless triggered by a by-law - i.e. through expansion).
  - v) Encourage the implementation of best management practices (BMP) for residences, commercial establishments and industrial properties.
  - vi) Verify that all private septic systems have been decommissioned properly on municipally serviced properties.
  - vii) Assess the existence, condition and containment of all AST and UST heating and fuelling tanks (both commercial and domestic). Geo-reference tank locations where possible.
  - viii) Inform people of the requirements to maintain heating/fuelling tanks (Liquid Fuels Handling Code, 2001 and Ont. Reg. 213/01).
  - ix) Properly abandon any remaining private septic systems on municipally serviced properties.
  - x) Ensure that heating/fuelling tank removals, replacements and/or improvements to required specifications have been completed within the 50-day WHPA.
- e) It is recommended the following tasks be completed within the high risk land-use areas of the 10 and 25 year WHPA as soon as possible after the 2 year zone has been completed ;
- i) Verify the existence, construction and use of all water supply wells. Geo-reference all well locations where possible.
  - ii) Abandon all wells not in use as required by the regulations and re-condition wells in use to current MOE standards.
  - iii) Establish an overburden and bedrock groundwater monitoring network. Geo-reference all monitoring well locations where possible.

- iv) Distribute and encourage the completion of the Commercial Contaminant Use Inventory/Questionnaire to all commercial/industrial establishments within Table 2. (voluntary unless triggered by a by-law - i.e. through expansion).
  - v) Encourage the implementation of best management practices (BMP) for residences, commercial establishments and industrial properties.
  - vi) Assess the existence, condition and containment of all AST and UST heating and fuelling tanks (both commercial and domestic). Geo-reference tank locations where possible.
  - vii) Properly abandon any remaining private septic systems on municipally serviced properties within the 2 year WHPA.
  - viii) Inform people of the requirements to maintain heating/fuelling tanks (Liquid Fuels Handling Code, 2001 and Ont. Reg. 213/01).
  - ix) Ensure that heating/fuelling tank removals, replacements and/or improvements to required specifications have been completed within the 2-year WHPA
- f) It is recommended the following tasks be completed within the moderate risk land-use areas of the 10 year WHPA and the low risk land-use areas of the 25 year WHPA as soon as possible after step (e) above has been completed;
- i) Verify the existence, construction and use of all water supply wells. Geo-reference all well locations where possible.
  - ii) Abandon all wells not in use as required by the regulations and re-condition wells in use to current MOE.
  - iii) Establish an overburden and bedrock groundwater monitoring network. Geo-reference all well locations where possible.
  - iv) Distribute and encourage the completion of the Commercial Contaminant Use Inventory/Questionnaire to all commercial/industrial establishments within Table 2 (voluntary unless triggered by a by-law - i.e. through expansion).
  - v) Encourage the implementation of best management practices (BMP) for residences, commercial establishments and industrial properties.
  - vi) Assess the existence, condition and containment of all AST and UST heating and fuelling tanks (both commercial and domestic). Geo-reference all tank locations where possible.
  - vii) Inform people of the requirements to maintain heating/fuelling tanks (Liquid Fuels Handling Code, 2001 and Ont. Reg. 213/01).

- viii) Ensure that heating/fuelling tank removals, replacements and/or improvements to required specifications are completed within this area and have been completed within the high risk land-use areas of the 10 and 25 year WHPA.
- 2) Recommendations with respect to the review of historical water quality are presented in memo dated July 13, 2004 entitled "Township of Finch Historical Raw Water Quality – Review and Recommendations".
- 3) It is recommended that the municipal well monitoring and inspection program be implemented as soon as possible.

Respectfully submitted,

  
per/ Tami Sugarman, B.Sc., P.Geo.  
Hydrogeologist/Project Manager

  
Robert Hillier, B.Sc., P.Geo.  
Client Manager



## 7.0 REFERENCES

Davidson, Laurence, Steve Holysh and John Mayes (2002). *An Assessment of Aquifer Vulnerability Mapping Methods for the Oak Ridges Moraine*. Ground and Water: Theory to Practice, Proceedings of the 55<sup>th</sup> Canadian Geotechnical and 3<sup>rd</sup> Joint IAH-CNC and CGS Groundwater Specialty Conferences, pp 1135 – 1142.

Kostuch Engineering Ltd. (March 2001). *Village of Finch Water System, Engineer's Report for Water Work*.

MOE (2001). Groundwater Studies 2001/2002, Technical Terms of Reference. *MOE Terms of Reference*.

Ontario Clean Water Agency (OWRC) (1971). *Report on a Groundwater Survey in the Village of Finch, Ontario Water Resources Commission, 1971*, Table 1 and Figure.

OCWA (October 2000 to March 2003). *Quarterly Reports on Drinking Water Quality*.

OCWA (January 1 to December 31, 2003). *Annual Report, Drinking –Water Systems Regulation O. Reg. 170/0*.

OCWA (2001, 2002, 2003 and up to March 2004). *Water Plant Performance Assessment Reports*.

Ontario Ministry of the Environment (June 2003). *Technical Support Document for Ontario Drinking Water Standards, Objectives and Guidelines*.

U.S. Environmental Protection Agency, Office of Ground-Water Protection, Office of Water (1987, ed. 1993). *Guidelines for Delineation of Wellhead Protection Areas*.




FIGURE: 1

## SITE LOCATION MAP

MAP REFERENCE:  
MINISTRY OF NATURAL RESOURCES  
10 18 4900 49950

B3018-SMAP

**WESA**  
A Better Environment For Business






FIGURE 3A:  
**POTENTIAL CONTAMINANT SOURCES IN THE VILLAGE OF FINCH**  
 FINCH WELLHEAD PROTECTION PLAN

## **APPENDIX A**

**EOWRC 2003 Report: Figure 5.1, Wellhead Protection Areas and Aquifer Intrinsic  
Susceptibility Map**

**APPENDIX B**

**Municipal Wells - MOE Well Records**



MINISTRY OF THE ENVIRONMENT  
The Ontario Water Resources Act  
**WATER WELL RECORD**

1. PRINT ONLY IN SPACES PROVIDED  
2. CHECK ☒ CORRECT BOX WHERE APPLICABLE

11

5801326

**MUNICI**

59

MUNICIP.  
5870A

COUNTY OR DISTRICT <b>STORMONT</b>		TOWNSHIP, CENSUS-GEOGRAPHIC VILLAGE <b>FINCH</b>		3 9		COM., BLOCK, TRACT, SURVEY, ETC.		LOT 28-29	
OWNER (SURNAME FIRST) <b>VILLAGE of FINCH</b>		28-47		ADDRESS <b>FINCH</b>		DATE COMPLETED DAY <b>12</b> MO. <b>07</b> YR. <b>72</b>			
31		TOWNE <b>1/8</b>		EASTING <b>493000</b>		NORTHING <b>4998760</b>		RC <b>4</b>	
						ELEVATION <b>0270</b>		RC <b>15</b>	
						BASIN <b>25</b>			

## LOG OF OVERBURDEN AND BEDROCK MATERIALS (SEE INSTRUCTIONS)

[illegible]

31	0005 01	0011 11	0189 1517			
32						

[illegible]

PUMP TEST	PUMPING TEST METHOD		1	PUMPING RATE		15-30	DURATION OF PUMPING	
	<input checked="" type="checkbox"/> X <input type="checkbox"/> BAILER		0120		GPM	72	15-30	17-40
						HOURS	00	WINS
	STATIC LEVEL	WATER LEVEL END OF PUMPING	2B WATER LEVELS DURING				<input checked="" type="checkbox"/> PUMPING <input type="checkbox"/> RECOVERY	
	010.21		22-24	15 MINUTES	30 MINUTES	45 MINUTES	60 MINUTES	
	<del>102.5</del> 052			029.30	029.30	031.30	031.30	
	FEET	FEET		FEET	FEET	FEET	FEET	
	IF FLOWING, GIVE RATE		30-43	PUMP INTAKE SET AT		WATER AT END OF TEST		45
				GPM		FEET	<input checked="" type="checkbox"/> CLEAR <input type="checkbox"/> CLOUDY	
	RECOMMENDED PUMP TYPE			RECOMMENDED PUMP SET			RECOMMENDED PUMPING RATE	
<input type="checkbox"/> SHALLOW <input checked="" type="checkbox"/> DEEP			40-45 0280			40-45 0110		
30-53			FEET			GPM		

<b>FINAL STATUS OF WELL</b>	<del>1</del> <input checked="" type="checkbox"/> WATER SUPPLY <del>2</del> <input type="checkbox"/> OBSERVATION WELL <del>3</del> <input type="checkbox"/> TEST HOLE <del>4</del> <input type="checkbox"/> RECHARGE WELL	<del>5</del> <input type="checkbox"/> ABANDONED, INSUFFICIENT SUPPLY <del>6</del> <input type="checkbox"/> ABANDONED, POOR QUALITY <del>7</del> <input type="checkbox"/> UNFINISHED
	1 <input type="checkbox"/> DOMESTIC 2 <input type="checkbox"/> STOCK 3 <input type="checkbox"/> IRRIGATION 4 <input type="checkbox"/> INDUSTRIAL <input type="checkbox"/> OTHER _____	<del>5</del> <input checked="" type="checkbox"/> COMMERCIAL <del>6</del> <input checked="" type="checkbox"/> MUNICIPAL <del>7</del> <input type="checkbox"/> PUBLIC SUPPLY 8 <input type="checkbox"/> COOLING OR AIR CONDITIONING <input type="checkbox"/> NOT USED
<b>WATER USE</b> <i>06</i>		
<b>METHOD OF DRILLING</b>	<del>1</del> <input checked="" type="checkbox"/> CABLE TOOL <del>2</del> <input type="checkbox"/> ROTARY (CONVENTIONAL) <del>3</del> <input type="checkbox"/> ROTARY (REVERSE) <del>4</del> <input type="checkbox"/> ROTARY (AIR) <del>5</del> <input type="checkbox"/> AIR PERCUSSION	<del>6</del> <input type="checkbox"/> BORING <del>7</del> <input type="checkbox"/> DIAMOND <del>8</del> <input type="checkbox"/> JETTING <del>9</del> <input type="checkbox"/> DRIVING

CONTRACTOR	NAME OF WELL CONTRACTOR	LICENSE NUMBER
	RAMON H. CASSELMAN	1505
	ADDRESS	
	WILLIAMSBURG	
	NAME OF DRILLER OR BORER	LICENSE NUMBER
	SIGNATURE OF CONTRACTOR	SUBMISSION DATE
		DAY _____ MO. _____ TR _____

LOCATION OF WELL

IN DIAGRAM BELOW SHOW DISTANCES OF WELL FROM ROAD AND LOT LINE. INDICATE NORTH BY ARROW.

WILLIAM ST.

JOHN ST.

75'

120'

DATE OF INSPECTION

DATE RECEIVED

CONTRACTOR

REMARKS

OFFICE USE ONLY

62-96

1

1505

190973

INSPECTOR

REMARKS:

Am



## WATER WELL RECORD

1. PRINT ONLY IN SPACES PROVIDED  
2. CHECK ☒ CORRECT BOX WHERE APPLICABLE

11

5801327

MUNICIP.  
5820A

CON

COUNTY OR DISTRICT <b>STORMONT</b>		TOWNSHIP - BOROUGH - CANTON - VILLAGE <b>FINCH</b>		CON.. BLOCK, TRACT, SURVEY ETC.		LOT 25-27	
OWNER (SURNAME FIRST) <b>VILLAGE of FINCH</b>		ADDRESS <b>FINCH</b>		DATE COMPLETED DAY <b>19</b> MO <b>JUN</b> YR <b>72</b>			
(21)	ZONE <b>151</b>	EASTING <b>493000</b>	NORTHING <b>4988750</b>	RC <b>15</b>	ELEVATION <b>1270</b>	BSIN - FEET <b>25</b>	

## LOG OF OVERBURDEN AND BEDROCK MATERIALS (SEE INSTRUCTIONS)

GENERAL COLOUR	MOST COMMON MATERIAL	OTHER MATERIALS	GENERAL DESCRIPTION	DEPTH - FEET	
				FROM	TO
	gravel	clay fill		0	5
	gravel			5	11
	limestone		solid	11	99
	"	broken		99	104
	"		solid	104	189
	F. HCH	WELL NO 2/72			

F. INCH	WELL N <sup>o</sup> 2/72
---------	--------------------------

[illegible]

32

41 WATER RECORD

WATER FOUND AT DEPTH	KIND OF WATER			
0-5	<input checked="" type="checkbox"/> FRESH	3	<input type="checkbox"/> SULPHUR	14
5-10	<input type="checkbox"/> SALTY	4	<input type="checkbox"/> MINERAL	15
10-15	1 <input type="checkbox"/> FRESH	3	<input type="checkbox"/> SULPHUR	16
	2 <input type="checkbox"/> SALTY	4	<input type="checkbox"/> MINERAL	17
20-25	1 <input type="checkbox"/> FRESH	3	<input type="checkbox"/> SULPHUR	20
	2 <input type="checkbox"/> SALTY	4	<input type="checkbox"/> MINERAL	21
25-30	1 <input type="checkbox"/> FRESH	3	<input type="checkbox"/> SULPHUR	22
	2 <input type="checkbox"/> SALTY	4	<input type="checkbox"/> MINERAL	23
30-35	1 <input type="checkbox"/> FRESH	3	<input type="checkbox"/> SULPHUR	34
	2 <input type="checkbox"/> SALTY	4	<input type="checkbox"/> MINERAL	35

### CASING & OPEN HOLE RECORD

INSIDE DIAMETER INCHES		MATERIAL		WALL THICKNESS INCHES		DEPTH - FEET	
						FROM	TO
10-11	1 <input checked="" type="checkbox"/> STEEL 2 <input type="checkbox"/> GALVANIZED 3 <input type="checkbox"/> CONCRETE 4 <input type="checkbox"/> OPEN HOLE	12		$\frac{1}{4}$	0	0028	27.9
17-18	1 <input type="checkbox"/> STEEL 2 <input type="checkbox"/> GALVANIZED 3 <input type="checkbox"/> CONCRETE 4 <input type="checkbox"/> OPEN HOLE	18				0028 (27.3)	28.9 018.9
24-25	1 <input type="checkbox"/> STEEL 2 <input type="checkbox"/> GALVANIZED 3 <input type="checkbox"/> CONCRETE 4 <input type="checkbox"/> OPEN HOLE	24					27.9

### PLUGGING & SEALING RECORD

DEPTH SET AT - FEET		MATERIAL AND TYPE	CEMENT GROUT LEAD PACKER ETC.
FROM	TO		
10-13	14-17		
18-21	22-25		
26-29	30-33	BO	

**PUMPING TEST METHOD**


PUMPING TEST	1 <input checked="" type="checkbox"/> PUMP 2 <input type="checkbox"/> BAILER		0120 GPM		06 19-16 00 HOURS TEST MINVS	
	STATIC LEVEL		25 WATER LEVELS DURING		3 <input checked="" type="checkbox"/> PUMPING 4 <input type="checkbox"/> RECOVERY	
	WATER LEVEL END OF PUMPING		15 MINUTES		30 MINUTES	
	0117-31 025 FEET		25-34 019 FEET		30-31 020 FEET	
	IF FLOWING, GIVE DATE		30-45 GPM		45 MINUTES	
	RECOMMENDED PUMP TYPE		PUMP INTAKE SET AT		60 MINUTES	
	<input type="checkbox"/> SHALLOW <input checked="" type="checkbox"/> DEEP		42-45 PUMP SETTING 080 FEET		35-37 020 FEET	
	50-53 008.6		1 <input type="checkbox"/> CLEAR 2 <input type="checkbox"/> CLOUDY		RECOMMENDED PUMPING RATE 0110 GPM	

**FINAL  
STATUS  
OF WELL**

WATER USE  06	1 <input type="checkbox"/> DOMESTIC 2 <input type="checkbox"/> STOCK 3 <input type="checkbox"/> IRRIGATION 4 <input type="checkbox"/> INDUSTRIAL <input type="checkbox"/> OTHER	5 <input checked="" type="checkbox"/> COMMERCIAL <input checked="" type="checkbox"/> MUNICIPAL 6 <input type="checkbox"/> PUBLIC SUPPLY 7 <input type="checkbox"/> COOLING OR AIR CONDITIONING <input type="checkbox"/> NOT USED
METHOD OF DRILLING	1 <input checked="" type="checkbox"/> CABLE TOOL 2 <input type="checkbox"/> ROTARY (CONVENTIONAL) 3 <input type="checkbox"/> ROTARY (REVERSE) 4 <input type="checkbox"/> ROTARY (AIR) 5 <input type="checkbox"/> AIR PERCUSSION	6 <input type="checkbox"/> BORING 7 <input type="checkbox"/> DIAMONG 8 <input type="checkbox"/> JETTING 9 <input type="checkbox"/> DRIVING

## LOCATION OF WELL

IN DIAGRAM BELOW SHOW DISTANCES OF WELL FROM ROAD AND LOT LINE. INDICATE NORTH BY ARROW.



**DRILLERS REMARKS:**

**CONTRACTOR**

NAME OF WELL CONTRACTOR <b>RAMON H. CASSELLMAN</b>		LICENCE NUMBER <b>1505</b>
ADDRESS <b>WILLIAMS BURG</b>		
NAME OF DRILLER OR BORER		LICENCE NUMBER
SIGNATURE OF CONTRACTOR	SUBMISSION DATE	

## OFFICE USE ONLY

DATA SOURCE	50	CONTRACTOR	39-02	DATE RECEIVED	62-00
1		1505		190973	
DATE OF INSPECTION		INSPECTOR			
REMARKS:					

UTM 118 Z 493100E

518 R 49987000N

Elev. 51 R 02225

Basin 25

County or District Stormont

Township, Village, Town or City Finch

Con. Plan 48

Lot 45

Date completed Dec. 30/61

(day month year)

Owner The Corporation of Village of Finch Address Finch Ontario.  
(print in block letters)

## Casing and Screen Record

## Pumping Test

Inside diameter of casing 4 in.

Total length of casing 21 ft.

Type of screen

Length of screen

Depth to top of screen

Diameter of finished hole 4 in.

Static level 6 ft. 60/ft

Test-pumping rate 800 GPH G.P.M.

Pumping level 39 ft.

Duration of test pumping 1 hr.

Water clear or cloudy at end of test Clear

Recommended pumping rate 800 GPH with 20 ft. tailpipe  
with pump setting of 40 ft. feet below ground surface

## Well Log

## Water Record

## Overburden and Bedrock Record

From  
ft.To  
ft.Depth(s) at  
which water(s)  
foundKind of water  
(fresh, salty,  
sulphur)

Boulders Sand Loam

0

7

Boulders Gravel Clay Sand

7

13

Limestone

13

93

85

fresh

For what purpose(s) is the water to be used?

Is well on upland, in valley, or on hillside? Upland

Drilling or Boring Firm Ramon H Casselman

Address Williamsburg Ontario

Licence Number 258


Name of Driller or Borer Lorne Barkley

Address Williamsburg Ontario

Date Dec. 30/61

Ramon H Casselman  
(Signature of Licensed Drilling or Boring Contractor)

## Location of Well

In diagram below show distances of well from  
road and lot line. Indicate north by arrow.

Form 7 15M Sets 60-5930

OWRC COPY





Ontario

MINISTRY OF THE ENVIRONMENT  
The Ontario Water Resources Act

# WATER WELL RECORD

316/3E

1. PRINT ONLY IN SPACES PROVIDED  
2. CHECK ☒ CORRECT BOX WHERE APPLICABLE

WELL NO. 5801908-1  
MUNICIP. 58.002 CON. CAN 03  
COUNTY OR DISTRICT Stormont TOWNSHIP, BOROUGH, CITY DRUMMONDVILLE CON. BLOCK, TRACT, SURVEY ETC. CONCESSION 3  
OWNER (SURNAME FIRST) United Counties - SDG ADDRESS Box 305 Finch DATE COMPLETED 30-09-77  
21 EASTING 493650 NORTHING 4998950 ELEVATION 627.5 BASIN CODE 26

## LOG OF OVERBURDEN AND BEDROCK MATERIALS (SEE INSTRUCTIONS)

GENERAL COLOUR	MOST COMMON MATERIAL	OTHER MATERIALS	GENERAL DESCRIPTION	DEPTH - FEET	
				FROM	TO
	<u>Hard Pan</u>			0	21
	<u>Bladders</u>			21	26
	<u>Limestone</u>			26	54

31 0021 1/4 0026 13/4 0056 15  
32

<b>41 WATER RECORD</b> WATER FOUND AT - FEET KIND OF WATER FRESH <input checked="" type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/> FRESH <input checked="" type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/> FRESH <input type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/> FRESH <input type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/> FRESH <input type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/> FRESH <input type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/> FRESH <input type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/> FRESH <input type="checkbox"/> SALTY <input type="checkbox"/> SULPHUR <input type="checkbox"/> MINERAL <input type="checkbox"/>	<b>51 CASING &amp; OPEN HOLE RECORD</b> INSIDE DIAM. INCHES MATERIAL WALL THICKNESS INCHES DEPTH - FEET FROM TO 10-16 STEEL 186 17-18 19-20 21-22 23-24 25-26 27-28 29-30 31-32 33-34 35-36 37-38 39-40 41-42 43-44 45-46 47-48 49-50 51-52 53-54 55-56 57-58 59-60 61-62 63-64 65-66 67-68 69-70 71-72 73-74 75-76 77-78 79-80 81-82 83-84 85-86 87-88 89-90 91-92 93-94 95-96 97-98 99-100 101-102 103-104 105-106 107-108 109-110 111-112 113-114 115-116 117-118 119-120 121-122 123-124 125-126 127-128 129-130 131-132 133-134 135-136 137-138 139-140 141-142 143-144 145-146 147-148 149-150 151-152 153-154 155-156 157-158 159-160 161-162 163-164 165-166 167-168 169-170 171-172 173-174 175-176 177-178 179-180 181-182 183-184 185-186 187-188 189-190 191-192 193-194 195-196 197-198 199-200 201-202 203-204 205-206 207-208 209-210 211-212 213-214 215-216 217-218 219-220 221-222 223-224 225-226 227-228 229-230 231-232 233-234 235-236 237-238 239-240 241-242 243-244 245-246 247-248 249-250 251-252 253-254 255-256 257-258 259-260 261-262 263-264 265-266 267-268 269-270 271-272 273-274 275-276 277-278 279-280 281-282 283-284 285-286 287-288 289-290 291-292 293-294 295-296 297-298 299-300 301-302 303-304 305-306 307-308 309-310 311-312 313-314 315-316 317-318 319-320 321-322 323-324 325-326 327-328 329-330 331-332 333-334 335-336 337-338 339-340 341-342 343-344 345-346 347-348 349-350 351-352 353-354 355-356 357-358 359-360 361-362 363-364 365-366 367-368 369-370 371-372 373-374 375-376 377-378 379-380 381-382 383-384 385-386 387-388 389-390 391-392 393-394 395-396 397-398 399-400 401-402 403-404 405-406 407-408 409-410 411-412 413-414 415-416 417-418 419-420 421-422 423-424 425-426 427-428 429-430 431-432 433-434 435-436 437-438 439-440 441-442 443-444 445-446 447-448 449-450 451-452 453-454 455-456 457-458 459-460 461-462 463-464 465-466 467-468 469-470 471-472 473-474 475-476 477-478 479-480 481-482 483-484 485-486 487-488 489-490 491-492 493-494 495-496 497-498 499-500 501-502 503-504 505-506 507-508 509-510 511-512 513-514 515-516 517-518 519-520 521-522 523-524 525-526 527-528 529-530 531-532 533-534 535-536 537-538 539-540 541-542 543-544 545-546 547-548 549-550 551-552 553-554 555-556 557-558 559-560 561-562 563-564 565-566 567-568 569-570 571-572 573-574 575-576 577-578 579-580 581-582 583-584 585-586 587-588 589-590 591-592 593-594 595-596 597-598 599-600 601-602 603-604 605-606 607-608 609-610 611-612 613-614 615-616 617-618 619-620 621-622 623-624 625-626 627-628 629-630 631-632 633-634 635-636 637-638 639-640 641-642 643-644 645-646 647-648 649-650 651-652 653-654 655-656 657-658 659-660 661-662 663-664 665-666 667-668 669-670 671-672 673-674 675-676 677-678 679-680 681-682 683-684 685-686 687-688 689-690 691-692 693-694 695-696 697-698 699-700 701-702 703-704 705-706 707-708 709-710 711-712 713-714 715-716 717-718 719-720 721-722 723-724 725-726 727-728 729-730 731-732 733-734 735-736 737-738 739-740 741-742 743-744 745-746 747-748 749-750 751-752 753-754 755-756 757-758 759-760 761-762 763-764 765-766 767-768 769-770 771-772 773-774 775-776 777-778 779-780 781-782 783-784 785-786 787-788 789-790 791-792 793-794 795-796 797-798 799-800 801-802 803-804 805-806 807-808 809-810 811-812 813-814 815-816 817-818 819-820 821-822 823-824 825-826 827-828 829-830 831-832 833-834 835-836 837-838 839-840 841-842 843-844 845-846 847-848 849-850 851-852 853-854 855-856 857-858 859-860 861-862 863-864 865-866 867-868 869-870 871-872 873-874 875-876 877-878 879-880 881-882 883-884 885-886 887-888 889-890 891-892 893-894 895-896 897-898 899-900 901-902 903-904 905-906 907-908 909-910 911-912 913-914 915-916 917-918 919-920 921-922 923-924 925-926 927-928 929-930 931-932 933-934 935-936 937-938 939-940 941-942 943-944 945-946 947-948 949-950 951-952 953-954 955-956 957-958 959-960 961-962 963-964 965-966 967-968 969-970 971-972 973-974 975-976 977-978 979-980 981-982 983-984 985-986 987-988 989-990 991-992 993-994 995-996 997-998 999-1000 1001-1002 1003-1004 1005-1006 1007-1008 1009-1010 1011-1012 1013-1014 1015-1016 1017-1018 1019-1020 1021-1022 1023-1024 1025-1026 1027-1028 1029-1030 1031-1032 1033-1034 1035-1036 1037-1038 1039-1040 1041-1042 1043-1044 1045-1046 1047-1048 1049-1050 1051-1052 1053-1054 1055-1056 1057-1058 1059-1060 1061-1062 1063-1064 1065-1066 1067-1068 1069-1070 1071-1072 1073-1074 1075-1076 1077-1078 1079-1080 1081-1082 1083-1084 1085-1086 1087-1088 1089-1090 1091-1092 1093-1094 1095-1096 1097-1098 1099-1100 1101-1102 1103-1104 1105-1106 1107-1108 1109-1110 1111-1112 1113-1114 1115-1116 1117-1118 1119-1120 1121-1122 1123-1124 1125-1126 1127-1128 1129-1130 1131-1132 1133-1134 1135-1136 1137-1138 1139-1140 1141-1142 1143-1144 1145-1146 1147-1148 1149-1150 1151-1152 1153-1154 1155-1156 1157-1158 1159-1160 1161-1162 1163-1164 1165-1166 1167-1168 1169-1170 1171-1172 1173-1174 1175-1176 1177-1178 1179-1180 1181-1182 1183-1184 1185-1186 1187-1188 1189-1190 1191-1192 1193-1194 1195-1196 1197-1198 1199-1200 1201-1202 1203-1204 1205-1206 1207-1208 1209-1210 1211-1212 1213-1214 1215-1216 1217-1218 1219-1220 1221-1222 1223-1224 1225-1226 1227-1228 1229-1230 1231-1232 1233-1234 1235-1236 1237-1238 1239-1240 1241-1242 1243-1244 1245-1246 1247-1248 1249-1250 1251-1252 1253-1254 1255-1256 1257-1258 1259-1260 1261-1262 1263-1264 1265-1266 1267-1268 1269-1270 1271-1272 1273-1274 1275-1276 1277-1278 1279-1280 1281-1282 1283-1284 1285-1286 1287-1288 1289-1290 1291-1292 1293-1294 1295-1296 1297-1298 1299-1300 1301-1302 1303-1304 1305-1306 1307-1308 1309-1310 1311-1312 1313-1314 1315-1316 1317-1318 1319-1320 1321-1322 1323-1324 1325-1326 1327-1328 1329-1330 1331-1332 1333-1334 1335-1336 1337-1338 1339-1340 1341-1342 1343-1344 1345-1346 1347-1348 1349-1350 1351-1352 1353-1354 1355-1356 1357-1358 1359-1360 1361-1362 1363-1364 1365-1366 1367-1368 1369-1370 1371-1372 1373-1374 1375-1376 1377-1378 1379-1380 1381-1382 1383-1384 1385-1386 1387-1388 1389-1390 1391-1392 1393-1394 1395-1396 1397-1398 1399-1400 1401-1402 1403-1404 1405-1406 1407-1408 1409-1410 1411-1412 1413-1414 1415-1416 1417-1418 1419-1420 1421-1422 1423-1424 1425-1426 1427-1428 1429-1430 1431-1432 1433-1434 1435-1436 1437-1438 1439-1440 1441-1442 1443-1444 1445-1446 1447-1448 1449-1450 1451-1452 1453-1454 1455-1456 1457-1458 1459-1460 1461-1462 1463-1464 1465-1466 1467-1468 1469-1470 1471-1472 1473-1474 1475-1476 1477-1478 1479-1480 1481-1482 1483-1484 1485-1486 1487-1488 1489-1490 1491-1492 1493-1494 1495-1496 1497-1498 1499-1500 1501-1502 1503-1504 1505-1506 1507-1508 1509-1510 1511-1512 1513-1514 1515-1516 1517-1518 1519-1520 1521-1522 1523-1524 1525-1526 1527-1528 1529-1530 1531-1532 1533-1534 1535-1536 1537-1538 1539-1540 1541-1542 1543-1544 1545-1546 1547-1548 1549-1550 1551-1552 1553-1554 1555-1556 1557-1558 1559-1560 1561-1562 1563-1564 1565-1566 1567-1568 1569-1570 1571-1572 1573-1574 1575-1576 1577-1578 1579-1580 1581-1582 1583-1584 1585-1586 1587-1588 1589-1590 1591-1592 1593-1594 1595-1596 1597-1598 1599-1600 1601-1602 1603-1604 1605-1606 1607-1608 1609-1610 1611-1612 1613-1614 1615-1616 1617-1618 1619-1620 1621-1622 1623-1624 1625-1626 1627-1628 1629-1630 1631-1632 1633-1634 1635-1636 1637-1638 1639-1640 1641-1642 1643-1644 1645-1646 1647-1648 1649-1650 1651-1652 1653-1654 1655-1656 1657-1658 1659-1660 1661-1662 1663-1664 1665-1666 1667-1668 1669-1670 1671-1672 1673-1674 1675-1676 1677-1678 1679-1680 1681-1682 1683-1684 1685-1686 1687-1688 1689-1690 1691-1692 1693-1694 1695-1696 1697-1698 1699-1700 1701-1702 1703-1704 1705-1706 1707-1708 1709-1710 1711-1712 1713-1714 1715-1716 1717-1718 1719-1720 1721-1722 1723-1724 1725-1726 1727-1728 1729-1730 1731-1732 1733-1734 1735-1736 1737-1738 1739-1740 1741-1742 1743-1744 1745-1746 1747-1748 1749-1750 1751-1752 1753-1754 1755-1756 1757-1758 1759-1760 1761-1762 1763-1764 1765-1766 1767-1768 1769-1770 1771-1772 1773-1774 1775-1776 1777-1778 1779-1780 1781-1782 1783-1784 1785-1786 1787-1788 1789-1790 1791-1792 1793-1794 1795-1796 1797-1798 1799-1800 1801-1802 1803-1804 1805-1806 1807-1808 1809-1810 1811-1812 1813-1814 1815-1816 1817-1818 1819-1820 1821-1822 1823-1824 1825-1826 1827-1828 1829-1830 1831-1832 1833-1834 1835-1836 1837-1838 1839-1840 1841-1842 1843-1844 1845-1846 1847-1848 1849-1850 1851-1852 1853-1854 1855-1856 1857-1858 1859-1860 1861-1862 1863-1864 1865-1866 1867-1868 1869-1870 1871-1872 1873-1874 1875-1876 1877-1878 1879-1880 1881-1882 1883-1884 1885-1886 1887-1888 1889-1890 1891-1892 1893-1894 1895-1896 1897-1898 1899-1900 1901-1902 1903-1904 1905-1906 1907-1908 1909-1910 1911-1912 1913-1914 1915-1916 1917-1918 1919-1920 1921-1922 1923-1924 1925-1926 1927-1928 1929-1930 1931-1932 1933-1934 1935-1936 1937-1938 1939-1940 1941-1942 1943-1944 1945-1946 1947-1948 1949-1950 1951-1952 1953-1954 1955-1956 1957-1958 1959-1960 1961-1962 1963-1964 1965-1966 1967-1968 1969-1970 1971-1972 1973-1974 1975-1976 1977-1978 1979-1980 1981-1982 1983-1984 1985-1986 1987-1988 1989-1990 1991-1992 1993-1994 1995-1996 1997-1998 1999-2000 2001-2002 2003-2004 2005-2006 2007-2008 2009-2010 2011-2012 2013-2014 2015-2016 2017-2018 2019-2020 2021-2022 2023-2024 2025-2026 2027-2028 2029-2030 2031-2032 2033-2034 2035-2036 2037-2038 2039-2040 2041-2042 2043-2044 2045-2046 2047-2048 2049-2050 2051-2052 2053-2054 2055-2056 2057-2058 2059-2060 2061-2062 2063-2064 2065-2066 2067-2068 2069-2070 2071-2072 2073-2074 2075-2076 2077-2078 2079-2080 2081-2082 2083-2084 2085-2086 2087-2088 2089-2090 2091-2092 2093-2094 2095-2096 2097-2098 2099-2100 2101-2102 2103-2104 2105-2106 2107-2108 2109-2110 2111-2112 2113-2114 2115-2116 2117-2118 2119-2120 2121-2122 2123-2124 2125-2126 2127-2128 2129-2130 2131-2132 2133-2134 2135-2136 2137-2138 2139-2140 2141-2142 2143-2144 2145-2146 2147-2148 2149-2150 2151-2152 2153-2154 2155-2156 2157-2158 2159-2160 2161-2162 2163-2164 2165-2166 2167-2168 2169-2170 2171-2172 2173-2174 2175-2176 2177-2178 2179-2180 2181-2182 2183-2184 2185-2186 2187-2188 2189-2190 2191-2192 2193-2194 2195-2196 2197-2198 2199-2200 2201-2202 2203-2204 2205-2206 2207-2208 2209-2210 2211-2212 2213-2214 2215-2216 2217-2218 2219-2220 2221-2222 2223-2224
--	---

## **APPENDIX C**

**Hazard Ratings for Potential Contaminant Sources  
(EOWRC report 2003, Table 5.1)**

### 5.5.1 Finch

The Finch production wells 1 and 2 are located in town to the immediate west of the arena. The wells are reported to be completed within the limestone aquifer. Potential sources of contamination within the immediate vicinity of the well lead are:

- The rail line located some 50 m to the north that just borders on the 50 day time of travel delineation.
- Across from the well head is a small abandoned foam insulation industry that is now believed to be used for storage. This facility is within the 2 year time of travel from the well head.
- The area to the west of the well head across the street is taken up by crop farming and falls within the 2 year time of travel from the well head.
- Approximately 20 to 30 metres north of the site is a welding shop with fuel tanks, this facility is with the 50 day time of travel delineation from the well head.
- The heating in Town is supplied by individual services and further east are County facilities that maintain fuel storage facilities.

A summary of the contaminant ranking of these potential threats is provided in Table 5.1.

**Table 5.1**  
**Ranking of Contaminant Threats - Finch**

Land Use Category	Time of Travel	Hazard Rating 1 - 10	ISI Rank 1 - 3	Risk Index 1-30 (5) (3) x (4)	Time of Travel Multiplier 1-4 (6)	Rank 0.1 -12 (7) (5)/10 x (6)	Landuse Risk Low, Med, High *
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
Finch							
Welding shops and oil tanks area	50 day	6.5	3	19.5	4	7.8	HIGH
Fuel outlets	outside 25 yr	6.5	3	19.5	1	1.95	LOW
Rail track to the north - oil	2 year	6.5	3	19.5	3	5.85	MEDIUM
Arena and parking to the west - oil	50 day	6.5	3	19.5	4	7.8	HIGH
Crop fields to the west	50 day	2	3	6	4	2.4	LOW
Home and funeral home to the south - home heating	2 year	6.5	3	19.5	3	5.85	MEDIUM
General residential -home heating	2 year	6.5	3	19.5	3	5.85	MEDIUM

0.1 - 3 = LOW  
3 - 7 = MEDIUM  
7 - 12 = HIGH

### 5.5.2 Moose Creek

The Moose Creek well system is located in the south end of Town. The closest sources that could provide a potential contaminant source would be homes that are located on the north side of the road that leads to the wells. These homes are approximately 100 m from the nearest well and have a septic system as well as residential heating. Although close to the well heads these locations are upgradient of the 50 day travel time zone. West of the wells, beyond the tree line is a farm with cultivated lands and a farm house. The farm house maintains a septic system, fuel tanks and likely chemical storage for farming. Further to the south and east, some two to three kilometers away, are residences and farms as well as deposits zoned for extraction. A summary of the contaminant ranking of these potential threats is provided in Table 5.2.

## **APPENDIX D**

**Evaluation Ranking System of Potential Risk for Contaminant Sources  
(EOWRC 2003 Report: Pages 71-72)**

**Type 1, Highest Potential Risk.**

- Private facilities for the disposal, storage, handling, transfer, processing and/or recycling of any solid or liquid wastes including private landfills
- Auto wrecking and salvage yards
- Earthen manure storage facilities
- Bulk storage of tires
- Petroleum products refining and asphalt batching
- Bulk storage of chemicals or hazardous substances, excluding on-site storage for agricultural production purposes
- Warehousing of cleaning products, pesticides, herbicides, fungicides and chemicals, excluding on-farm storage for agricultural production purposes
- Warehousing or the bulk storage of oil, gasoline or petroleum products
- Intensive livestock operations and associated manure storage facilities and land application of manure

**Type 2, Medium Potential Risk**

- Lagoons for sewage treatment
- Land application of biosolids or septage
- Golf courses
- Cemeteries
- Retail sale of agricultural fertilizers and pesticides
- Foundries
- Non-ferrous metal smelting and refining
- Metal casting operations
- Metal finishing operations (electroplating, electrocoating, galvanizing, painting, application of baked enamel)
- Assembly of aircraft and aircraft parts, motor vehicles, truck, bus bodies, trailers, rail cars, mobile homes, ships and boats
- Vehicle stampings
- Commercial or industrial dry cleaning of textiles and textile products
- Leather tanning and finishing
- Wood and wood product preservation and treatment
- Automobile service stations retail fuel sales (gas bars or card-lock facilities)
- Manufacturing of unfinished fabricated metal products and parts
- Manufacturing of cable and wire
- Manufacturing of jewellery and precious metals
- Manufacturing of engines, engine parts, steering and suspension parts, wheels and brakes
- Manufacturing of agricultural, commercial and industrial machinery
- Manufacturing of chemicals, resins, paints, varnish, printing inks, adhesives, plastics and reinforced fibreglass plastic
- Manufacturing of pharmaceuticals and medicines
- Manufacturing of electronic components such as semiconductors, printed circuit boards and cathode ray tubes
- Manufacturing of wet electrical equipment and wet batteries
- Manufacturing of motor vehicle wiring
- Manufacturing and dyeing of textiles
- Bulk road salt storage
- Snow storage and disposal facilities


### Type 3, Low Potential Risk

- Market gardening farms
- Automated production of baked goods, dairy, canned goods, frozen foods, processed food and meat
- Automated manufacturing of soft drinks, distilleries, breweries and wine making
- Abattoirs
- Dead stock removal operations
- Rendering facilities
- Photographic developing facilities
- Printing of newspaper, packaging and books
- Repair of photographic equipment, electrical motors, electrical equipment, vending Machines, small motors, appliances, computer equipment and jewellery
- Repair of motor vehicles, water craft, rail vehicles, trucks, buses and machinery
- Airports
- Transit terminals
- Medical, health and other laboratories
- Storage, repair yards and facilities for contractors
- Asphalt paving and roofing contractor yards
- Lawn care contractors
- Funeral homes
- Machinery equipment and rental outlets
- Manufacturing of rubber products
- Manufacturing of electrical appliances, equipment, motors, lighting fixtures, lamps
- Manufacturing of electric light bulbs and tubes
- Manufacturing of dry batteries
- Manufacturing of soaps and toiletry preparations
- Manufacturing of plastic and foam parts and products
- Furniture, casket, cabinet and other wood products manufacturing and assembly
- Glass and glass products manufacturing
- Manufacturing of paper, newsprint, boxes

Table 5.4 relates each of the land uses to the time of travel distance and the intrinsic susceptibility ranks. This information may be used in planning well head protection strategies.

**APPENDIX E**

**Township of North Stormont: Zoning By-law Map of Area**





# Schedule 'A'


JLR N° 84-8603

North Arrow



scale 1:40,000



township boundary   
 sub-schedule area (See Schedule 'B') 

## Legend

### Residential

- first density R1
- rural RR
- mobile home subdivision RMHS
- mobile home park RMHP

- Commercial - general C
- highway CH

- Industrial - restricted M
- rural MR

Institutional IOpen Space OTent and Trailer Park TPRural RUAgricultural AWrecking Yard WYWaste Disposal WDMineral Aggregate-pit MP-quarry MQ-reserve area MAHazard Land H- special exception -(numeral)

Notes &amp; Revisions

## **APPENDIX F**

### **Risk Strategies Implemented by other Ontario Municipalities**

## **RISK AVOIDANCE**

The following paragraphs summarize some of the risk avoidance strategies implemented in other municipalities in North America.

The majority of groundwater protection plans implemented to date in Canada and the United States use legislative changes to by-laws, official plans and zoning regulations. This method provides the municipality with the legislative authority to enforce the required changes that is not offered through voluntary programs. For example, Regina, Saskatchewan restricts any industrial land uses in WHPA's that use hazardous chemicals. New Brunswick regulates the quantities and types of chemicals that can be stored or used by new or existing businesses in WHPA's. Existing businesses that cannot meet the restrictions must move, some businesses being granted up to 15 years for this move. In Dayton, Ohio, companies within WHPA's had to compile an inventory of the type and quantity of chemicals they had on site at the time the regulation was passed. The companies are not allowed to increase the inventory, type and quantity, even if production increased or the company wished to expand. Because of the economic impact that this imposed on industrial facilities, the municipality of Dayton spent tens of millions of dollars over the last 20 years to assist up to 80% of the businesses in WHPA's to move to other locations. All of these examples can be classified as avoidance, or chemical restriction methods.

The Regional Municipality of Waterloo (Waterloo) has been addressing this issue of greenfield vs. developed property dilemma. In their case, proposed changes to greenfield sites have largely been accepted by the community and industry, although the by-laws have not yet been revised. For those properties that are currently developed they had intended to stipulate that these businesses did not meet the new by-laws and they would be deemed legal, but classified as non-conforming. The intent was to allow for increased flexibility for the existing industries however the business community rejected the stigma attached to the property especially if a property were to be sold.

The County of Oxford in southern Ontario is reportedly close to implementing groundwater protection policies. Land-use restrictions are being proposed for WHPA's similar to that proposed for Waterloo. Components of their policies for WHPA's include:

- prohibiting the use of underground storage tanks
- prohibiting any new development based on private wells or septic systems
- very stringent protocols for intense livestock operations
- development agreements could have more stringent storm water runoff requirements including the feasibility of at-source infiltration, increased design criteria, impact analysis and mitigation measures

The Oxford policies are a good example that groundwater protection should not be limited just to well head protection areas. Their policies will restrict land-uses in Environment Protection Areas (EPA) (such as Provincially Significant Wetlands) or require an Environmental Impact Study on lands contiguous to an EPA. There will be permitted, banned and conditional land-uses in recharge areas. In these areas, current businesses or new businesses would have to submit a disclosure report (i.e. essentially a chemical inventory with operational procedures). The County may also require a contingency plan in the event of a spill, site plan approval with a view on groundwater protection measures (i.e. BMPs) and groundwater monitoring programs. The policies also include measures for the redevelopment of contaminated or potentially contaminated land including historical review, soil and groundwater investigation, remedial action plans and MOE approval of those plans. Oxford's legal counsel has reviewed the policies and has the opinion that although they could be challenged, they are defensible at the Ontario Municipal Board (OMB) level.

### **RISK MANAGEMENT**

To better control *future* activities on *developed* properties within the WHPA, Waterloo is proposing the use of a Development Permit System (DPS) that would only apply to existing businesses in WHPA's that wish to expand beyond their current boundaries or when a site is to be re-used. In this way, current businesses could proceed with current operations, but when they want to expand, or sell the property, the DPS would require the business to implement best management practices to ensure that the land-use is of equal or less risk than the existing land-use. The DPS cannot be implemented at this time since the Ministry of Municipal Affairs and Housing, which originally approved its use on a pilot basis, has acknowledged that new provincial legislation has to be implemented in order for the DPS to work effectively. It is not known when or if this legislation will be introduced.

### **COSTS TO IMPLEMENT WELL HEAD PROTECTION STRATEGIES**

The cost to change By-laws to restrict land-use of greenfield properties is an internal cost for the Municipality. Such activities will have to be integrated into the Municipality's action items. Public Meetings and consultation will be part of the process as with any other changes to the existing By-laws.

In cases where there are existing industries, incentives could be provided to encourage them to move out of the WHPA. Incentives could include subsidies to businesses that are to move out of the area or subsidies to landowners whose property is devalued due to change of land-use. This can be very costly as seen in the Dayton, Ohio example mentioned above. If the municipality decides it is too costly and/or difficult to move high risk activities out of the WHPA, chemical restriction policies could be required. The municipality must decide whether such a program will be a voluntary one, or if it intends to enforce such an activity. As mentioned earlier different implementation strategies have been tried in Ontario. It appears the permitting option may be most easily

implemented. Unfortunately, this would only include those establishments that are undergoing some change to trigger the permitting. For those that do not fall under the permitting obligations, they may be encouraged to participate through incentive programs.

The cost to implement the restriction of chemical use lies primarily in the monitoring and enforcement of the restrictions. These additional costs would be incurred primarily through the hiring of additional staff to ensure implementation of the program is followed.

Workshops are also very effective educational tools that can reach a large number of businesses at one time. The Municipality could subsidize the information Workshops. Participants could be asked to pay a nominal fee, such as \$50, to ensure attendance. The municipality would, therefore, have to subsidize the event to include the costs of the presenters, room rental, food and audiovisual equipment. The costs of a typical workshop would be approximately \$5000. Detailed training for all applicable employees at a specific business on items such as Transportation of Dangerous Goods and Emergency Response typically range from \$2000 to \$5000 per facility.

The Business Water Quality Program (BWQP) in the Region of Waterloo provides financial and technical assistance to businesses to implement BMPs that prevent water pollution. The first step in the Program is a Facility Review and Assessment completed by a pre-qualified consultant (including WESA) who assesses the potential for spills to groundwater, surface water or sewer systems and then recommends procedural and/or capital BMPs. Procedural BMPs include employee training, spill prevention or pollution prevention plans and Environmental Management Systems (EMSs). Capital BMPs include facility and structural improvements, equipment purchases or process changes. In Waterloo, the program pays 50% of the initial assessment costs up to a maximum of \$4000. None of the assessments conducted to date have exceeded \$8000. The program also provides grants to implement the BMPs on a 50% cost share basis up to a maximum of \$14,000. The Region has committed \$1.5 million over the 5 years of the Program with additional funding being provided by the MOE and Environment Canada. The Program is administered by an outside agency (OCETA – Ontario Centre for Environmental Technology Advancement). This is an example of the type of incentive program that could be established for the study area. The level of environmental awareness is greatly increased for each business participating in the BWQP in the Region of Waterloo.

## **APPENDIX G**

### **MOE Terms of Reference Questionnaires and Examples of Best Management Practices for Industry and Commercial Establishments**

(Insert name of study region here)

## Groundwater Study

### Business/Chemical Use Inventory

Date: \_\_\_\_\_

Please fax to (phone #) by: \_\_\_\_\_

#### 1. Facility Information

Facility Name: \_\_\_\_\_ ☐ Completed at time of visit  
Street Address: \_\_\_\_\_ ☐ Left for business to complete  
Georeferenced Location: Latitude: \_\_\_\_\_ Longitude: \_\_\_\_\_ ☐ Not completed

Person Interviewed: \_\_\_\_\_

Title: \_\_\_\_\_ Phone: \_\_\_\_\_

Name for the Mailing: \_\_\_\_\_ Title: \_\_\_\_\_

Mailing Address: \_\_\_\_\_

City: \_\_\_\_\_ Prov: \_\_\_\_\_ Postal Code: \_\_\_\_\_

Did you know your facility is located close to a municipal well? ☐ Yes ☐ No

If known, please indicate any previous facilities on the

#### 2. Type of Service/Product

NAICS code: \_\_\_\_\_

(refer to Terms of Reference, Schedule D)

##### Facility Type:

<input type="checkbox"/> Office	<input type="checkbox"/> Restaurant	<input type="checkbox"/> Medical	<input type="checkbox"/> Agriculture: Livestock Operations
<input type="checkbox"/> Gas Station	<input type="checkbox"/> Industry	<input type="checkbox"/> Dry Cleaner	<input type="checkbox"/> Agriculture: Crops/Nursery
<input type="checkbox"/> Computers	<input type="checkbox"/> Waste Management	<input type="checkbox"/> Automotive	<input type="checkbox"/> Printer/Photo Processor
<input type="checkbox"/> Manufacturing	<input type="checkbox"/> Other _____		

#### 3. Materials Handling

How do you dispose of waste? ☐ On site ☐ Off site  
Is spill cleanup equipment available? ☐ Yes ☐ No  
Is there a septic system on site? ☐ Yes ☐ No ☐ Unknown  
Are there floor drains in the shop? ☐ Yes ☐ No ☐ Unknown

Any wells on site?	Industrial Use Well	<input type="checkbox"/>	Number of Wells: _____
	Abandoned/Unused Well	<input type="checkbox"/>	Number of Wells: _____
	Irrigation Well	<input type="checkbox"/>	Number of Wells: _____
	Drainage Well	<input type="checkbox"/>	Number of Wells: _____
	Drinking Water Well	<input type="checkbox"/>	Number of Wells: _____
	Observation Well	<input type="checkbox"/>	Number of Wells: _____

Is there an Environmental Mgt System in Place? ☐ Yes ☐ No Date Initiated \_\_\_\_\_

### Microbiological Contaminants Storage

	Estimated Volume	Type of Storage Container			Physical State (Sol/Liq/Gas)
		Earthen	Concrete	Metal	
Biosolids (e.g., pulp/paper waste)	_____	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Septage	_____	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Sewage Sludge	_____	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Agricultural Manure	_____	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Other Animal Waste	_____	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____

### Organic Contaminants Storage

	Liquid	<25L (<5 gal)	25-250L (5-50 gal)	250-2500L (50-500 gal)	>2500L (>500 gal)	Above Ground Tank	Below Ground Tank	Physical State (Sol/Liq/Gas)
	Solid	<25Kg	25-250Kg	250-2500Kg	>2500Kg			
Petroleum Products	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Insecticides/ Herbicides	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Brake/Transmission Fluid	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Acids/Bases/Caustics	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Paints/Dyes/Stains	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Cleaning Solutions (soap, detergents, etc.)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Chlorinated Solvents (degreasers, dry cleaning fluid, TCE, etc.)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Other Solvents (MEK, MIBK, acetone, varsol, etc.)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Film Chemicals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____
Registered Wastes (PCBs, asbestos, etc.)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	_____

### Inorganic Contaminants Storage

	Estimated Volume	Physical State (Sol/Liq/Gas)
Fertilizers	_____	_____
Salt	_____	_____
Other _____	_____	_____



### 5. Landscape Application of Materials

	Yes	No	Estimated Area of Application
Nutrients (manure, biosolids)	<input type="checkbox"/>	<input type="checkbox"/>	_____
Fertilizers	<input type="checkbox"/>	<input type="checkbox"/>	_____
Pesticides	<input type="checkbox"/>	<input type="checkbox"/>	_____
Salt (e.g., paved surfaces)	<input type="checkbox"/>	<input type="checkbox"/>	_____
Other _____	<input type="checkbox"/>	<input type="checkbox"/>	_____

Comments: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

# Water Pollution Prevention Fact Sheet

## - Accommodation Service Industries -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Use physical rather than chemical cleaning methods wherever possible.
- Do not put potentially hazardous materials down the sink/drain. Have them properly disposed by a licensed hazardous waste hauler.
- Use automated systems for laundry chemicals
- Reduce pesticide applications by using non-chemical pest control measures.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Closed-loop cooling systems should be used to save water and costs.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Health and Social Service Industries -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Do not install floor drains in x-ray processing rooms, labs, or where regulated medical wastes are stored.
- Use amalgam traps in dental offices to prevent silver and mercury bearing amalgams from entering the subsurface disposal system or sanitary sewer.
- Increased septic system detention times may improve BOD removal from the discharge of blood, formaldehyde and other degradable wastes.
- Dispose of spent or obsolete products through a vendor or medical waste collection service.
- Reduce solvent use by minimizing sizes of cultures or specimens, and using calibrated solvent dispensers.
- Reuse formaldehyde solutions in lab applications.
- Isolate and secure medical wastes, infectious wastes and biomedical wastes from other solid wastes and store in appropriate containers. Transport and dispose according to regulations.
- Use physical rather than chemical cleaning methods wherever possible.
- Wastewater from lab operations should discharge to a lab drain system that is separate from the sanitary wastewater drains. Lab drains should lead to a neutralization system before discharging to the sanitary sewer.
- Do not put potentially hazardous materials down the sink/drain. Have them properly disposed by a licensed hazardous waste hauler.
- Implement a hazardous waste minimization program. Reduce hazardous wastes by substituting with non-hazardous materials
- Large institutions can set up satellite waste accumulation areas, allowing each area to accumulate 205 L of hazardous waste. Each area must be managed by a person directly responsible for the process producing the waste.
- Use on-site distillation and filtration equipment to regenerate solvents and other chemicals.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Consider a bulletin board solely for environmental concerns.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Food and Beverage Service Industries -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Consider composting all leftover and off-spec food waste.
- Set up a system to collect all grease, fat and meat and bone scraps. Contract a rendering facility to pick up these materials for use in manufacturing animal feed and tallow.
- Implement a preventative maintenance program for all kitchen appliances and equipment.
- Fast Food outlets should have a centrally located receptacle for pre-consumer food scraps. The waste can be composted or given to local farmers for animal feed.
- Use physical rather than chemical cleaning methods wherever possible.
- Do not put potentially hazardous materials down the sink/drain. Have them properly disposed by a licensed hazardous waste hauler.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize

opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.

- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebsscctt@oceta.on.ca](mailto:ebsscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998




# Water Pollution Prevention Fact Sheet

## *- Personal and Household Service Industries-*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinsewaters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Increased septic system detention times may improve BOD removal from the discharge of blood, formaldehyde and other degradable wastes.
- Mixing areas for pesticides should be located indoors, away from floor drains.
- Any floor drains in buildings used for the storage and mixing of fertilizers and pesticides should be connected to a holding tank not to a septic system or sanitary sewer.
- Dry cleaning exhaust vents should be equipped to capture any dripping liquids.
- Dry-to-dry machines eliminate the need to transfer solvent laden garments from a washer to a dryer, reducing solvent and solvent vapour loss.
- Conduct regular hazardous waste audits and implement hazardous waste minimization programs.
- Lint filters, lint, sludge, exhaust condensate and waste solvents should be disposed through a licensed hauler.
- Carefully meter the formulation of hair dyes, permanent waves, and frosting/bleaches to minimize excessive wastes.
- Reduce the frequency of solvent replacement to reduce solvent use and handling. Use on-site solvent recovery and recycling systems.
- Encourage the use of products with longer shelf lives and which can be reused if excess is generated.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998





transportation procedures for WHMIS materials to reduce the risk of spills and accidents.

- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.

- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebsectt@oceta.on.ca](mailto:ebsectt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Amusement and Recreational Service Industries -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Use physical rather than chemical cleaning methods wherever possible.
- Mixing areas for pesticides should be located indoors, away from floor drains.
- Any floor drains in buildings used for the storage and mixing of fertilizers and pesticides should be connected to a holding tank not to a septic system or sanitary sewer.
- Pesticide containers can be disposed of at landfills if they are emptied in accordance with hazardous waste regulations.
- Rinse waters from pesticide containers and application equipment can be diluted and spread on turf or crops.
- Pesticide use must be registered and applied according to authorized uses, label directions and applicable regulations.
- Do not put potentially hazardous materials down the sink/drain. Have them properly disposed by a licensed hazardous waste hauler.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebsttt@oceta.on.ca](mailto:ebsttt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Samia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.samia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - General Retail Merchandising

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Spent solvents and ink sludges should be stored in secure containers and disposed of through a licensed hazardous waste hauler.
- Large commercial and medical facilities should not discharge spent solutions to septic systems.
- Spent photographic fixer and developer should be stored in secure containers, recycled or disposed of through a licensed hazardous waste transporter.
- Photographic wastes should be treated to remove silver and other metals before discharging. Make sure the treated waste meets the applicable effluent guidelines.
- Set up a staff waste reduction and pollution prevention committee.
- Keep staff informed about company pollution prevention programs, policies and objectives.
- Provide clearly labeled waste containers for source separation or train cleaning staff to source separate materials.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water.
- Recycle cleaning rags or rags contaminated with ink, paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Minimize the use of materials such as road salts and lawn-care chemicals.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Department & General Store Retail Merchandising

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Set up a staff waste reduction and pollution prevention committee.
- Keep staff informed about company pollution prevention programs, policies and objectives.
- Fast Food outlets should have a centrally located receptacle for pre-consumer food scraps. The waste can be composted or given to local farmers for animal feed.
- Provide clearly labeled waste containers for source separation or train cleaning staff to source separate materials.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as

required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.

- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of  
Waterloo –  
Water Services  
Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca  
/water/  
docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental  
Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email:  
[ebsttt@oceta.on.ca](mailto:ebsttt@oceta.on.ca)

**Canadian Centre for  
Pollution Prevention  
(C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada  
Green Lane**  
Web page:  
[Www.cciw.ca/green-  
Lane/or-home.html](http://www.cciw.ca/green-Lane/or-home.html)

NOTES ON YOUR POLLUTION PREVENTION OR BEST MANAGEMENT PRACTICES...



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Local Government Services -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Oil traps and oil/grit separators can be installed in storm sewer catch basins. Remove trapped oil and grease after each storm.
- Sump sediments from sealed catch basins should be removed at least twice a year.
- To reduce the amount of nutrients and pesticides in stormwater runoff, towns should encourage reductions in fertilizer and pesticide use for lawns, golf courses and agricultural lands.
- Set up a staff waste reduction and pollution prevention committee.
- Keep staff informed about office/department pollution prevention programs, policies and objectives.
- Provide clearly labeled waste containers for source separation or train cleaning staff to source separate materials.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material



Regional Municipality of Waterloo – Water Services Division

Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998





saturated with oil is a hazardous waste and should be disposed properly.

- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize

opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.

- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of  
Waterloo –  
Water Services  
Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca  
/water/  
docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental  
Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email:  
[ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for  
Pollution Prevention  
(C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.sarnia.com>

**Environment Canada  
Green Lane**  
Web page:  
[www.cciw.ca/green-  
lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Schools and Educational Service Industries-

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Wastewater from lab operations should discharge to a lab drain system that is separate from the sanitary wastewater drains. Lab drains should lead to a neutralization system before discharging to the sanitary sewer.
- Do not put potentially hazardous materials down the sink/drain. Have them properly disposed by a licensed hazardous waste hauler.
- Implement a hazardous waste minimization program.
- Large institutions can set up satellite waste accumulation areas, allowing each area to accumulate 205 L of hazardous waste. Each area must be managed by a person directly responsible for the process producing the waste.
- Reduce hazardous wastes by substituting with non-hazardous materials.
- Use on-site distillation and filtration equipment to regenerate solvents and other chemicals.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Closed-loop cooling systems should be used to save water and costs.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



transportation procedures for WHMIS materials to reduce the risk of spills and accidents.

- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.

- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Samia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Business Service Industries -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Set up a staff waste reduction and pollution prevention committee.
- Keep staff informed about office/department pollution prevention programs, policies and objectives.
- Provide clearly labeled waste containers for source separation or train cleaning staff to source separate materials.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.

- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.

- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)

---

NOTES ON YOUR POLLUTION PREVENTION OR BEST MANAGEMENT PRACTICES...



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Wholesale Machinery, Equipment and Supplies -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



them regularly for recycling, reuse or proper disposal.

- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.

- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - General Wholesale Products Industries-

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998





them regularly for recycling, reuse or proper disposal.

- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.

- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Retail Household Furniture and Appliances -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Parts cleaning and degreasing areas should be isolated from other operations. The area should have a permeable floor and some form of containment in case of a spill.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Discarded or damaged parts should not be left with the client for disposal after servicing.
- Segregate waste paint from waste thinner, since waste thinners can be recycled for use as a precleaning solvent.
- Use one multi-purpose solvent rather than many different types to minimize waste, improve recyclability and reuse.
- Dumpsters containing scrap metal should have a drain plug in place, be covered and located on a concrete pad.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.



Regional Municipality of Waterloo – Water Services Division

Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Samia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)

---

NOTES ON YOUR POLLUTION PREVENTION OR BEST MANAGEMENT PRACTICES...



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Automotive Vehicles, Parts & Accessories - Sales-*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Each service bay should be provided with a waste collection station which include labeled containers for each type of waste liquid or labeled sinks which lead to an appropriate waste holding tank.
- Service pits should have spill containment such as a sump which discharges to a holding tank.
- Store large quantities of lead-acid batteries in covered, isolated areas with no floor drains, acid resistant flooring, and secondary containment. Small quantities can be stored in acid-resistant tubs.
- Each car wash facility should maximize the recycling/reuse of rinse water.
- Floor drains should connect to an oil/water separator system.
- Service pits should have impervious, concrete floors. Old earthen floors should be checked for historical contamination and remediated as necessary.
- Check hydraulic lifts regularly for leaks.
- Vehicle storage and repair areas must have an impermeable surface and some form of containment in case of spills or leaks.
- Use above ground hydraulic lift systems whenever possible
- Dedicate service bays to a specific operation such as parts cleaning, degreasing, engine steam cleaning, vehicle washing etc. This will make waste handling more efficient.
- Do not use antifreeze as a de-icing agent. Antifreeze can be recovered on-site or off-site.
- Do not use waste oil as a dust suppressant.
- Waste paints, thinners, paint sludges and solids should be collected, drummed, labeled and disposed by a licensed waste hauler.
- Waste from the collection tank of an oil/water separator should be emptied every 6 to 12 months by a licensed waste hauler.
- Send waste solvent to a waste exchange for further reuse and recycling.
- If no floor drains are installed, there should be no vehicle washing and there should be no discharges to environment of any kind.
- Install a drying rack and/or drip pan to collect solvents dripping off of washed parts. Reuse the collected solvent.
- Use high performance oils to reduce the frequency of changes and the amount of waste produced.
- Used oil filters should be recycled for their scrap metal content. Drain (for at least 24 hrs.) and collect the residual oil prior to recycling.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Retail Food, Beverage and Drug -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Waste from the produce department is excellent composting material or animal feed. Look for local markets for this material and/or let customers and local farmers know about it.
- Scraps from the meat department can be used in the manufacturing of animal feed.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebsscctt@oceta.on.ca](mailto:ebsscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Samia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.samia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)

---

NOTES ON YOUR POLLUTION PREVENTION OR BEST MANAGEMENT PRACTICES...



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Wholesale Metals, Hardware, Plumbing, Heating & Building Materials-

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998





- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Transportation Industries -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Salt storage and mixing facilities should not be located within recharge areas for water supply wells. They should be located on flat sites, with impermeable surfaces protected from run-off.
- Salt piles should be stored under cover.
- Floor drains in maintenance bays should be connected to a holding tank or sanitary sewer which is equipped with an oil and grit separator.
- Collect any saline water that may develop in a tight drainage system. Collected brine can be dried and reused.
- Environmentally sensitive areas should be identified for all road crews. Make sure all crew members now how to protect these areas.
- Avoid dumping snow directly into rivers or other water courses.
- Batteries that are cracked and leaking are considered a hazardous waste. Dispose of them through a hazardous waste transporter. Intact batteries should be reclaimed.
- Do not mix oil or diesel fuel waste with anything.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Trade Contracting Industries -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Quickly stabilize disturbed areas by restoring overburden, replacing topsoil, avoiding steep slopes, reproducing natural drainage patterns, and replacing vegetation.
- Topsoil and subsoil should be stripped from the operation area and kept for restoration of the area.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of  
Waterloo –  
Water Services  
Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
Www.region.waterloo.on.ca/  
a/water/  
docs/wateresouc.html

**Environmental  
Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email:  
ebsctt@oceta.on.ca

**Canadian Centre for  
Pollution Prevention  
(C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: c2p2@sarnia.com  
http://c2p2.sarnia.com

**Environment Canada  
Green Lane**  
Web page:  
www.cciw.ca/green-  
lane/or-home.html



Regional Municipality of Waterloo – Water Services Division  
Website:  
www.region.waterloo.on.ca/water/docs/wateresouc.html  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Storage and Warehousing -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Maintain an accurate inventory of materials stored on site. Investigate any changes in volume that may be due to leaks or spills.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Loading docks should be covered to prevent stormwater from mixing with any spilled chemicals.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Closed-loop cooling systems should be used to save water and costs.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
[Http://c2p2.sarnia.com](http://c2p2.sarnia.com)

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - Wholesale Motor Vehicle, Parts and Accessories-

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998





them regularly for recycling, reuse or proper disposal.

- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.

- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Building, Developing and General Contracting -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Quickly stabilize disturbed areas by restoring overburden, replacing topsoil, avoiding steep slopes, reproducing natural drainage patterns, and replacing vegetation.
- Topsoil and subsoil should be stripped from the operation area and kept for restoration of the area.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebstt@oceta.on.ca](mailto:ebstt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## - All Industries and Businesses -

Everyday business practices can pollute our local groundwater, rivers and lakes. There are many Pollution Prevention Practices which we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinsewaters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Closed-loop cooling systems should be used to save water and costs.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, September, 1998



- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo –  
Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, September, 1998



# Water Pollution Prevention Fact Sheet

## - Quarry and Sand Pit -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Sand and gravel pits make groundwater especially vulnerable to contamination due to the permeable nature of their deposits. Mining activities should be located away from recharge areas of aquifers needed for public water supplies.
- Quickly stabilize disturbed areas by restoring overburden, replacing topsoil, avoiding steep slopes, reproducing natural drainage patterns, and replacing vegetation.
- Topsoil and subsoil should be stripped from the operation area and kept for restoration of the area.
- Incorporate appropriate drainage systems to prevent ground and surface water contamination. Drainage should not lead directly into streams or ponds.
- Limit active gravel removal to a total of five acres at any one time to minimize the amount of surface area susceptible to erosion.
- Ensure that access roads are constructed and maintained properly so as to prevent or control erosion.
- Maintain an adequate vertical separation between the deepest depth of excavation and the maximum high water table elevation.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



them regularly for recycling, reuse or proper disposal.

- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as

required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.

- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Samia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.samia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)

---

NOTES ON YOUR POLLUTION PREVENTION OR BEST MANAGEMENT PRACTICES...



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, September, 1998



# Water Pollution Prevention Fact Sheet

## - Plastic Products Manufacturing -

Everyday business practices can pollute our local groundwater, rivers and lakes. There are many Pollution Prevention Practices which we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Untreated rinsewaters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Closed-loop cooling systems should be used to save water and costs.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.
- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Minimize the use of materials such as road salts and lawn-care chemicals.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, September, 1998





- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo –  
Water Services Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, September, 1998



# Water Pollution Prevention Fact Sheet

## *- Fabricated Metal Product Manufacturing -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- All degreasing operations should be carried out in a properly working vapour degrease. Consider installing a vapour degreaser solution distillation system.
- Uncovered scrap metal storage areas should have a separate stormwater collection system with an oil/grit separator which discharges to a sanitary sewer or a holding tank.
- Only use water for cooling and lubrication.
- Use a recirculating bath and reusable filter system to recycle grinding fluids.
- Parts cleaning and degreasing areas should be isolated from other operations, and located within a containment area with an impermeable floor. There should be no direct access to outside.
- Incorporate appropriate drainage systems to prevent ground and surface water contamination. Drainage should not lead directly into streams or ponds.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Keep drain plugs in dumpsters and drums containing oil coated scrap metal. Collect oil/water liquid and dispose through a licensed waste hauler.
- Reduce the frequency of solvent replacement to reduce consumption and handling. Decant sludges from solvent tanks to extend the life of the solvent.
- Reduce the volume of oil used per machine, filter the oil, and increase the recirculation rate to reduce the amount of waste oil generated.
- Extend solvent life by using a two stage rinsing process with "dirty" and "clean" solvent baths.
- Preclean parts with a rag or wire brush. Then steam clean, high-pressure wash, or use an recycling aqueous solution hot bath with an oil/water separator.
- If hot water, detergent or alkaline solutions are not adequate, use a non-chlorinated organic solvent.
- Water soluble cutting fluids can be substituted for more hazardous oils.
- Use water based rather than solvent based paints.
- Use one multi-purpose solvent.
- Eliminate the organic solvents from tumbling operations.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Consider a bulletin board solely for environmental concerns.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebsctt@oceta.on.ca](mailto:ebsctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, September, 1998



# Water Pollution Prevention Fact Sheet

## - General Manufacturing Industries -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Containers holding hazardous wastes must be tightly closed throughout the period of accumulation, except during waste addition or removal.
- Antifreeze can contaminate groundwater. Dispose of it properly through a hazardous waste transporter.
- Clean paint guns in a secure container with a high quality, nonchlorinated solvent.
- Untreated rinse waters or floor drains should not discharge to a sanitary sewer, septic system, storm drain or surface water.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Tanks and pipe fittings should be leak tested periodically for structural integrity. Annual testing of unprotected steel tanks and piping systems should be performed, especially for those aged 15 years or more.
- Waste collection stations, with labeled containers for each kind of waste, should be provided throughout work areas for spent chemicals, soiled rags, etc.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Uncovered receiving areas should be designed with a spill sump to catch and store any spilled chemicals with manual operation for emptying.
- Do not let rainwater runoff come into contact with materials and wastes.
- Find out where your water drains. Drainage should not lead directly into streams or ponds. Cross-connections, such as sanitary discharges to storm sewers or floor drain discharges to storm sewer systems should be identified and eliminated. Install backflow preventors on water supply lines.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Closed-loop cooling systems should be used to save water and costs.
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Use dry cleanup methods and mopping, and avoid flooding with water. Absorbent material saturated with oil is a hazardous waste and should be disposed properly.
- Recycle cleaning rags or rags contaminated with paint, solvents, grease or oil, and have them cleaned by an industrial launderer.



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



- Purchase products in refillable, reusable or at least recyclable containers. Ask suppliers to take back containers.
- Recycle materials such as used oil, spent degreaser, and mineral spirits.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Use spigots, pumps or funnels for the transfer of materials to reduce spillage.
- Ordinary drums may have to be handled as hazardous waste unless they are properly cleaned before disposal. Discharge cleaning residues properly.
- Whenever possible, use environmentally friendly materials.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.
- Hazardous materials are not permitted in the sanitary or storm sewers (Sewer Use By-Law 1-90). Call (519)650-8260 for information on Regional By-Law 1-90.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of Waterloo – Water Services Division**  
 150 Frederick Street  
 7<sup>th</sup> Floor  
 Kitchener, ON N2G 4J3  
 Phone: 519-575-4426  
 Fax: 519-575-4424  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental Business Source (CTT)**  
 437-150 Frederick Street  
 Kitchener, ON, N2G 4J3  
 Phone: 519-579-4795  
 Fax: 519-575-4542  
 Email: [ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for Pollution Prevention (C2P2)**  
 100 Charlotte Street  
 Sarnia, ON, N7T 4R2  
 Phone: 1-800-667-9790  
 Fax: 519-337-3486  
 Email: [c2p2@sarnia.com](mailto:c2p2@sarnia.com)  
<http://c2p2.sarnia.com>

**Environment Canada Green Lane**  
 Web page:  
[www.cciw.ca/green-lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)



Regional Municipality of Waterloo – Water Services Division  
 Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
 Version 1.1, November, 1998



# Water Pollution Prevention Fact Sheet

## *- Paper and Related Product Manufacturing -*

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- Place solvent vapour curtains around equipment to increase the amount of solvent recovered and recycled.
- Use water based inks rather than solvent based inks whenever possible.
- Incorporate appropriate drainage systems to prevent ground and surface water contamination. Drainage should not lead directly into streams or ponds.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- New and waste material storage areas should be roofed, isolated from floor drains, have sealed surfaces, and be accessible to authorized personnel only.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overfill protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Consider a bulletin board solely for environmental concerns.
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty them regularly for recycling, reuse or proper disposal.
- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.
- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998



**Regional Municipality of  
Waterloo –  
Water Services  
Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca  
/water/  
docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental  
Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email:  
[ebscctt@oceta.on.ca](mailto:ebscctt@oceta.on.ca)

**Canadian Centre for  
Pollution Prevention  
(C2P2)**  
100 Charlotte Street  
Samia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.samia.com>

**Environment Canada  
Green Lane**  
Web page:  
[www.cciw.ca/green-  
lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)

---

NOTES ON YOUR POLLUTION PREVENTION OR BEST MANAGEMENT PRACTICES...



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, September, 1998



# Water Pollution Prevention Fact Sheet

## - Agricultural Industries -

Everyday business practices can pollute our groundwater, rivers and lakes. There are many Pollution Prevention Practices that we can use to prevent water pollution. Many of these Pollution Prevention Practices are simple to do, yet are very effective in keeping chemicals and wastes from harming our environment. Pollution prevention can be inexpensive, while pollution cleanup can cost thousands of dollars. Some of the Pollution Prevention Practices that were developed by people in your industry are listed below.

- A concrete walled storage area with a sloping floor can be used to store solid and liquid manure. A roof should be provided to prevent manure run-off due to rain or snow melt.
- Floor drains in pesticide mixing or storage areas should connect to a holding tank, not to the septic system.
- Manure pits should be lined with clay or other impermeable material. Pits must be large enough to handle the volume of waste generated until weather soil and crop conditions allow spreading.
- Incorporate appropriate drainage systems to prevent ground and surface water contamination. Drainage should not lead directly into streams or ponds.
- Pesticides used must be registered and applied according to authorized uses, label directions and applicable regulations.
- Wastes collected in a holding tank must be disposed through a licensed waste hauler.
- Never apply more manure or fertilizer than is needed. Too much can result in poor crop performance, water pollution and excessive odours. Consider soil types, crop type, acreage, and type of manure/fertilizer when determining application rates.
- Restrict cattle access to streams by putting up permanent or temporary fencing.
- Protect ditch banks and water courses by planting permanent grass buffer strips. Buffer areas filter run-off and control erosion.
- Liquid Storage areas must have secondary containment to hold any spills or leaks at 10% of the total volume of the containers, or 110% of the volume of the largest container, whichever is larger.
- Underground storage tanks (USTs) should not be used, unless required by fire codes or other regulations. Above ground storage tanks (ASTs) are preferred. Tanks should have visual gauges to monitor fluid levels. Routinely check all ASTs and USTs for leaks. Nozzles used for filling tanks should have automatic shutoff valves.
- If USTs must be used, they require secondary containment monitoring, high level and leak sensing audio/visual alarms, level indicators and overflow protection. A protective plate should be placed at the tank bottom if a dip stick is used.
- Dry wells should be eliminated. All unused wells must be abandoned (Ontario Regulation 903).
- Employees must have WHMIS training. Train all staff on proper handling, storage and transportation procedures for WHMIS materials to reduce the risk of spills and accidents.
- Keep track of where and why spills have occurred to prevent future spills.
- Cover crops and green manure crops protect the soil, add organic matter and control the leaching of crop nutrients.
- Any banned or outdated pesticides should be disposed properly through a licensed hazardous waste hauler.
- Perform preventative maintenance and manage equipment and materials to minimize opportunities for leaks, spills, evaporative losses and other releases of potentially toxic chemicals.
- An operator should be on-site at all times to monitor the filling of tanks and drums.
- Drip pans should be used under spigots of chemical and oil containers to catch spills. Empty



Regional Municipality of Waterloo – Water Services Division  
Website:

[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

Version 1.1, November, 1998





them regularly for recycling, reuse or proper disposal.

- Develop a spill prevention and clean-up plan. Include notification procedures, site plans with storm water flow directions, and potential spill sources. Clean spills promptly and report as

required. The Region's Spills reporting number is (519) 650-8200; Ontario's is 1-800-268-6060.

- Use emergency spill kits and equipment. Locate them in storage areas, loading and unloading areas, dispensing areas, and work areas.

---

The Regional Municipality of Waterloo has a Water Resources Protection Strategy to limit the risk of contamination of our water resources. The Region has compiled a list of Pollution Prevention Practices for most businesses in the Region. For additional information on pollution prevention and Pollution Prevention Practices contact the following:

**Regional Municipality of  
Waterloo –  
Water Services  
Division**  
150 Frederick Street  
7<sup>th</sup> Floor  
Kitchener, ON N2G 4J3  
Phone: 519-575-4426  
Fax: 519-575-4424  
[www.region.waterloo.on.ca  
/water/  
docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)

**Environmental  
Business Source (CTT)**  
437-150 Frederick Street  
Kitchener, ON, N2G 4J3  
Phone: 519-579-4795  
Fax: 519-575-4542  
Email:  
[ebsectt@oceta.on.ca](mailto:ebsectt@oceta.on.ca)

**Canadian Centre for  
Pollution Prevention  
(C2P2)**  
100 Charlotte Street  
Sarnia, ON, N7T 4R2  
Phone: 1-800-667-9790  
Fax: 519-337-3486  
Email: [c2p2@samia.com](mailto:c2p2@samia.com)  
<http://c2p2.sarnia.com>

**Environment Canada  
Green Lane**  
Web page:  
[www.cciw.ca/green-  
lane/or-home.html](http://www.cciw.ca/green-lane/or-home.html)

---

NOTES ON YOUR POLLUTION PREVENTION OR BEST MANAGEMENT PRACTICES...



Regional Municipality of Waterloo – Water Services Division  
Website:  
[www.region.waterloo.on.ca/water/docs/wateresouc.html](http://www.region.waterloo.on.ca/water/docs/wateresouc.html)  
Version 1.1, September, 1998





## TECHNICAL STANDARDS & SAFETY AUTHORITY

HOME CONTACT US SUBSCRIBE SITE MAP EMAIL THIS PAGE

Search For ...

### Fuels

TRANSPORTATION FUELS

HEATING FUELS

REGULATIONS & UPDATES

ENVIRONMENTAL SERVICES

CERTIFICATION STANDARDS

DISCRETIONARY SERVICES

FIELD APPROVALS

CLIENT NEWSLETTERS

PRODUCTS

PRODUCT RECALLS

CONTACTS & LINKS

APPLICATION FORMS

FEES

FREQUENT QUESTIONS

OTHER TSSA PROGRAMS

FUELS HOME

**Reporting  
a fuels  
incident**

### Information Bulletin

- [New Safety Laws To Prevent Fuel Oil Leaks and Spills](#)
- [New Fuel Oil Requirements \(Frequently Asked Questions\)](#)
- [Variance Applications for Abandonment of Underground Storage Tanks in Place](#)

### New Safety Laws To Prevent Fuel Oil Leaks and Spills

(November 2002) The Technical Standards and Safety Authority (TSSA) is advising all owners of fuel oil heating systems of the requirement to have their heating systems inspected by qualified oil burner technicians, and the need to register their underground (buried) fuel oil storage tanks with TSSA. New requirements were introduced in October 2001 to reduce the number of fuel oil leaks and spills that occur throughout the province each year.

TSSA investigation statistics show that old, rusting underground tanks and poorly maintained and defective heating systems are the leading sources of fuel oil leaks and spills. These leaks and spills can result in serious environmental damage and costly clean-up repairs for homeowners.

The new regulations require fuel oil distributors to conduct inspections on all fuel oil heating systems. This includes all underground and aboveground tanks, associated piping, venting and heating appliances such as furnaces, boilers and water heaters. The fuel oil distributor must inspect all equipment to which they deliver fuel, whether it is located above or below ground, initially and at least once every 10 years. **Fuel oil cannot be delivered to equipment that poses an immediate hazard.**

Most fuel oil spills are preventable by a simple inspection during regular maintenance and by replacing aged or defective components. Please contact your local fuel oil supplier for more information about the inspection requirements for your heating system.

If you own a buried fuel oil tank, it must be upgraded with leak and spill protection equipment or removed. Your first step is to register your tank, free of charge, with the Technical Standards and Safety Authority (TSSA). **Your fuel supplier may refuse to fill your underground tank if it is not registered with TSSA.** This does not include oil tanks in basements and aboveground fuel storage tanks. The provincial regulations include a phased-in, multi-year program to upgrade or remove these tanks. If your underground fuel tank was installed:

- 25 or more years ago? the tank must be upgraded or removed by **October 1, 2006**
- 20 to 24 years ago? the tank must be upgraded or removed by **October 1, 2007**
- 10 to 19 years ago? the tank must be upgraded or removed by **October 1, 2008**
- Less than a year to 9 years ago? the tank must be upgraded or removed by **October 1, 2009**

To register your underground tank and find out more about the new inspection requirements, please call TSSA's Fuels Safety program at (416) 734-3300 / toll-free at 1-877-682-TSSA (8772).

### New Fuel Oil Requirements (Frequently Asked Questions)

## FUEL OIL DISTRIBUTOR INSPECTIONS

### Why were the new inspection requirements introduced?

The new requirements were introduced in 2001 to address safety and environmental concerns with fuel oil installations. Many fuel oil leaks and spills are attributed to equipment failure that may have been preventable with an inspection.

A fuel oil user whose fuel oil installation leaks also faces substantial costs to clean up the resulting environmental contamination, not to mention the risk of liability in the event of an accident. The potential for personal injury and environmental harm resulting from improperly maintained or inappropriately used fuel oil installations is both unacceptable and avoidable. Fuel oil users have a responsibility to ensure that their equipment is in compliance with safety regulations to minimize these risks wherever they live.

### Can you provide details about these new requirements?

The new regulations require that the entire fuel oil system (associated piping, venting and heating appliance: such as furnaces, boilers and water heaters) must be inspected by distributors before they can receive fuel. Periodic inspections - at least once every 10 years - must be performed by distributors on each fuel oil system.

### What exactly is on the tank inspection checklist?

First, it is important to realize your fuel oil system consists of more than a storage tank. It includes a fill and vent pipe for oil supply and an outlet line with a valve and filter to supply the oil to your furnace. So when we discuss the oil system, we are really talking about all of these components. Keep in mind any one of these components can fail causing a leak or spill.

Some of the things your fuel dealer will be looking at during the inspection include:

- verifying the tank has a proper gauge and an overfill protection device
- checking whether the tank is leaning over and may topple
- checking whether there are signs of leakage at the tank bottom
- ensuring that the fill and vent are piped outside.

### What happens if the fuel oil supplier finds an unsafe installation?

Depending on the danger from the unsafe installation, a fuel supplier can specify a time period up to 90 days for corrective action or the delivery of fuel oil will cease. If the unsafe installation is very dangerous, then the distributor must immediately stop the supply of fuel oil to the installation.

### Who can fix my appliance and make it safe again?

All heating contractors working on fuel oil equipment are required to be registered with TSSA. When calling a heating contractor, ask for the contractor's TSSA registration number and request that only a TSSA certified Oil Burner Technician work on the appliance. To check if the contractor is registered with TSSA call 1-877-682-TSSA (8772).

### I don't agree with my fuel supplier and I think that my equipment is safe. What can I do?

Tank owners can get a second opinion from other Oil Burner Technicians and other Fuel Oil Suppliers to confirm whether or not there is an unsafe installation.

### I have a natural gas/propane furnace, does this apply to me?

No. While natural gas and propane-fuelled appliances have similar requirements, they are governed under different regulations. For more information on regulations governing natural gas and propane appliances, visit our Web site at [www.tssa.org](http://www.tssa.org).

### What regulation governs fuel oil and where can I get a copy?

Fuel oil is governed under the Technical Standards and Safety Act, and Ontario Regulation, 213/01. You can obtain a copy from the TSSA Web site at [www.tssa.org](http://www.tssa.org) or order a copy from the Ontario Government Bookstore at 1-800-668-9938.

## UNDERGROUND FUEL OIL TANKS

### What are the new requirements?

In October 2001, new fuel oil regulations administered by TSSA came into effect. The new regulations require registration of all underground fuel tanks in Ontario by May 2002.

**Why were they introduced?**

The new requirements were introduced to address safety and environmental concerns with underground fuel oil installations. Fuel tank leaks can lead to environmental hazards.

A fuel oil user whose tank leaks also faces substantial costs to clean up the resulting contamination, not to mention the risk of liability in the event of an accident. The potential for personal injury and environmental harm resulting from improperly maintained or inappropriately used tanks is both unacceptable and avoidable. Fuel oil users have a responsibility to ensure that their equipment is in compliance with safety regulations to minimize these risks wherever they live.

**What's the problem with underground fuel tanks?**

Many underground oil tanks in Ontario are 25 years old and older, or of an unknown age. These tanks are not specially protected from corrosion, as newer tanks are. As a result they may be leaking and should be upgraded or removed.

Leaking fuel oil tanks will contaminate soil and groundwater. The cost of cleaning up contamination from a leaking underground tank can range from \$5,000 to over \$1,000,000.

**Why weren't these new fuel oil requirements introduced before?**

No attention was paid to fuel oil leaks and spills for years before the hazards were fully understood. Once the nature of the hazards were apparent, the new requirements were introduced to correct existing problems and to prevent spills and leaks in the future.

**Why do I have to register my underground tank?**

By registering the tank, TSSA will be able to keep track of the location and condition of underground fuel oil tanks in Ontario. These new regulations will help to protect Ontario's environment from possible fuel oil leaks by creating a registry of the location and condition of each underground tank in the province and by ensuring that fuel oil tanks that are in danger of leaking do not receive fuel oil.

**How do I register?**

An Underground Fuel Oil Application Form must be completed and filed with TSSA. The application forms are available on our Web site at [www.tssa.org](http://www.tssa.org) or from our Fuels Safety program at 1-877-682-8772. A registration number will be assigned to your tank that you can give to your fuel distributor to ensure uninterrupted fuel supply.

**How can I tell if my underground tank is leaking?**

Because they are buried, it is difficult to tell if the tank is leaking. Some underground tanks may leak for years without owners realizing it. However, if your oil consumption suddenly goes up your tank may have sprung a large leak.

There are companies that test underground tanks for leaks. Call the Ontario Petroleum Contractors Association at (705) 735-9437 to help you find underground tank testing companies.

**What do I do if my underground tank is leaking?**

Call a TSSA registered fuel oil contractor to help you find and stop the leak and clean up any leaked fuel oil. You are also required to call the Spills Action Centre of the Ministry of Environment at 1-800-268-6060 to report the leak. Your insurance company may also be able to assist you.

**How do I remove my underground tank?**

Underground tanks are required to be removed by TSSA registered fuel oil contractors. A certified Petroleum Equipment Mechanic Two "PM2" is required to perform the removal. When you call a contractor, ask for the TSSA registration number. When an underground tank is removed, the soil around the tank must be assessed for contamination and all contamination cleaned. The costs associated with the removal of underground fuel oil storage tanks will vary depending on the location of the tank. Owners are encouraged to obtain competitive quotes for the removal of their underground storage tank.

**I have an underground tank that I am no longer using, what should I do?**

Once an underground tank stops being used, or where it hasn't been used in two years the underground tank is required to be removed and all contaminated soil cleaned. The removal is to be performed by a Petroleum Equipment Mechanic Two "PM2".

**Who are TSSA Registered Contractors?**

By law, all contractors working on fuel oil equipment such as underground tanks are required to be registered with TSSA. Persons repairing, installing, removing and servicing fuel oil underground tanks are also required

to be trained and certified as a "Petroleum Equipment Mechanic 2." The Ontario Petroleum Contractors Association may be able to refer you to some good TSSA registered fuel oil contractors.

**Who pays for the upgrading or removing of underground tanks?**

Owners of underground tanks are responsible for the costs of maintaining, upgrading, and removing their underground tank.

While we are concerned with the economic burden this may place on homeowners, the investment in these environmental upgrades will reduce the incidence of fuel spills, and offset the much higher potential costs for the clean-up of contaminated sites. The environmental hazards from spills are too great to ignore. Unfortunately, there has been a number of spills which have occurred as a result of defective fuel oil installations.

**How much time do I have to upgrade or remove my tank?**

TSSA has established a phased-in approach for fuel oil tank removal or upgrade over several years to assist owners in managing the associated costs.

The schedule guidelines call for tanks older than 25 years by October 2001 (including tanks whose age cannot be determined) must be replaced or upgraded by October 2006. Owners of tanks between 20 and 24 years old have an additional year to do this work, while tanks between 10 and 19 years must be replaced or upgraded by October 2008. Tanks less than nine years old in 2001 must be replaced or upgraded by October 2009.

**My insurance company wants my buried tank removed within 30 days, who is right TSSA or my insurance company?**

An insurance company can set their standards higher than what the regulations require. For example, they may determine they will not insure tanks of a certain age, as each insurance company is able to make its own determination of the liability they are willing to assume.

**What do the regulations say about upgrading basement or above ground tanks?**

There are no requirements in the regulations or Code that make upgrading of these tanks mandatory. Some insurance companies set their standards higher than TSSA and may require these tanks to be upgraded as well.

---

**Variance Applications for Abandonment of Underground Storage Tanks in Place****Background**

Under the Liquid Fuels Handling Code and the Fuel Oil Code all underground storage tanks (UST's) must be removed within two years of disuse. This code requirement is for safety purposes as old steel tanks may corrode and leave a void in the ground that may cause the ground to collapse. Secondly, abandoned USTs left with product in them may leak and cause an environmental impact. Under the TSS Act, an applicant may make application to seek a variance from this code requirement provided they give alternative actions that meet the intended safety requirements. [More...](#)

▲ [Back to top](#)

[Home](#) [Contact Us](#) [Subscribe](#) [Site Map](#) [Email This Page](#)  
[Disclaimer](#) [Privacy Policy](#)

Copyright © 2004 Technical Standards and Safety Authority. All Rights Reserved.

To view and print Adobe Portable Document Format (PDF) files  
download the most recent version of Adobe Acrobat Reader (free software):



**APPENDIX H**

**Well log Summary and Location Map of Village of Finch Wells**

**from**

*Report on a Groundwater Survey in the Village of Finch, Ontario Water Resources  
Commission, 1971*

ONTARIO WATER RESOURCES COMMISSION

AREA OF SURVEY VILLAGE OF FINCH

COUNTY STORMONT

TABLE OF WATER WELL RECORDS

TABLE 1

DATE JAN/71

RECORDER D.F.M.

Well No.	Location	Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc
485	VILLAGE OF FINCH	HENRY DAPIER	M. LEDUC 1949	9	4	35	8	2.7	15	S	D	HARDPAN 0-15 LIMESTONE 15-35 WATER AT 35
186	"	WILLIAM JOHNSON	M. LEDUC 1950	9	4	100	8	0.5	23	F	D	HARDPAN 0-8 LIMESTONE 8-100 WATER AT 88
87	"	RENE GAULAIS	RENE GAULAIS 1950	9	4	23	3	8.3	20	F	D	HARDPAN 0-7 GREY ROCK 7-23 WATER AT
188	"	H.G. BROWNLEE	M. LEDUC 1950	9	4	50	6	1.25	-	B	D	HARDPAN 0-6 LIMESTONE 6-50 WATER AT 48
9	"	SCAMERON	M. LEDUC 1950	9	4	34	8	1.25	-	F	D	HARDPAN 0-3 LIMESTONE 3-34 WATER AT 33
190	"	ALLAN MCDOUGUE	M. LEDUC 1951	9	4	26	8	3.3	20	F	D	LIMESTONE 0-26 WATER AT 8
491	"	ALBERT CHERAIER	M. LEDUC 1952	9	4	27	6	8.3	6	F	D	HARDPAN 0-8 ROCK 8-27 WATER AT
492	"	T. DWAR	M. LEDUC 1955	9	4	50	6	1.67	DRY	F	D	HARDPAN 0-8 GREY LIMESTONE 8-50 WATER AT 50
493	"	MERRITT CAMPBELL	M. LEDUC 1955	9	4	50	5	0.3	7	F	D	LIMESTONE 0-50 WATER AT 48
494	"	BASIL GILLIES	M. LEDUC 1955	9	4	35	OVER RUN	3.3		F	D	LIMESTONE 0-35 WATER AT 34
495	"	LORNE CAMPBELL	M. LEDUC 1955	9	4	35	6	5	12	F	D	LIMESTONE 0-35 WATER AT 35
496	"	F. HOOPIE	M. LEDUC 1955	9	4	55	7	5	7	F	D	HARDPAN 0-8 GREY LIMESTONE 8-55 WATER AT 48

## ONTARIO WATER RESOURCES COMMISSION

AREA OF SURVEY \_\_\_\_\_

## TABLE OF WATER WELL RECORDS

 DATE JAN/71

 COUNTY SOREMONT

 RECORDER D.F.M.

Well No.	Location	Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
497	VILLAGE OF FINCH	GEORGE DENE	M. LEDUC 1955	?	4	50	8	4.2	30	F	D	HARD PAN 0-8 DARK GREY LIMESTONE 8-50 WATER AT 48.
498	"	ARCHIE CASSELMAN	M. LEDUC 1956	?	4	47	6	4.2	20	F	D	HARD PAN 0-6 LIMESTONE 6-47 WATER AT 46
499	"	MURCH MILLER	M. LEDUC 1956	?	4	34	5	4.2	34	F	D	HARD PAN 0-27 LIMESTONE 27-34 WATER AT 34.
500	"	FINCH PUBLIC SCHOOL	M. LEDUC 1957	?	4	50	5	8.3	5	F	SCHOOL	HARD PAN 0-8 LIMESTONE 8-50 WATER AT 50.
501	"	A. CASSELMAN	R. CASSELMAN 1957	?	5	109	8	10	70	F	D	PERSON 0-15 TILL 15-6 LIMESTONE 6-109 WATER AT 100
502	"	POST OFFICE	R. SANCHE 1961	?	4	50	5	5	5	S	POST OFFICE	HARD PAN 0-5 CLAY 5-12 GRAY LIMESTONE 12-50 WATER AT 22
503	"	CORPORATION OF FINCH	R. CASSELMAN 1961	?	4	93	6	13.3	39	F	D	SANDS, SAND, CLAY 0-7 BONKERS, GRACK, CLAY, SAND, 7-13 LIMESTONE 13-9 WATER AT 85
504	"	CHARNE ARNSTEIN	G. CHARBONNAN 1963	?	6	130	6	12	15	F	D	CLAY LOOSESTON 0-15 GRAY LIMESTONE 15-127 WHITE SANDSTONE 127-130 WATER AT 130
505	"	N. WISEMAN	A. GAUTHIER 1963	?	4	35	5	4	30	F	D	LIMESTONE 0-35 WATER AT 30.
506	"	GLTA MURPHY	A. GAUTHIER 1963	?	4	45	5	8	25	F	D	HARD PAN 0-5 LIMESTONE 5-45 WATER AT 42
523	"	MRS BEEHNER	M. LEDUC 1953	?	4	31	8	4.2	6	F	D	HARD PAN 0-10 GRAY LIMESTONE 10-31 WATER AT 31
525	"	KEITH JOHNSON	A. GAUTHIER 1961	?	4	28	12	15	20	F	D	HARD PAN 0-12 LIMESTONE 12-28 WATER AT 25



## TABLE OF WATER WELL RECORDS

AREA OF SURVEY \_\_\_\_\_  
COUNTY STEELE

[illegible]

AREA OF SURVEY TOWNSHIP OF FINCHCOUNTY STORMONT

## ONTARIO WATER RESOURCES COMMISSION

## TABLE OF WATER WELL RECORDS

DATE JAN/71RECORDER D.F.M.

Well No.	Location			Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
508	TOWNSHIP OF FINCH	1	5	DONALD CASSELMAN	M. LEDUC 1965	9	4	65	10	5	35	F	FARM.	HARDPAN 0-12 LIMESTONE 12-65 WATER AT 63
509	"	1	5	DONALD CASSELMAN	R. CASSELMAN 1963	9	4	92.5	21	8.3	60	F	FARM.	OLD WELL 0-61.5 LIMESTONE 61.5-92.5 WATER AT 90
510	"	1	7	BOGAR McLEAN	R. CASSELMAN 1963	9	5	216			DRY		FARM.	0-21 OLD WELL LIMESTONE 21-216
511	"	1	7	BOGAR McLEAN	R. CASSELMAN 1963	9	5	100			DRY		FARM.	TOP SOIL 0-1 BEDDED CLAY 1-4 LIMESTONE 4-100
512	"	1	7	BOGAR McLEAN	R. CASSELMAN 1963	9	5	110			DRY		FARM.	CLAY GRAVEL 0-5 CLAY GRAVEL 5-20 LIMESTONE 20-110
513	"	1	7	BOGAR McLEAN	R. CASSELMAN 1963	9	6	36	9	5	26	F	STOCK	LOAM 0-2 CLAY SAND GRAVEL 2-19 FINE SAND 19-20 LIMESTONE 20-36 WATER AT 20
514	"	1	9	GEORGE McLEAN	A. GAUTHIER 1967	9	5	66	10	5	55	F	FARM.	HARDPAN 0-3 LIMESTONE 3-66 WATER AT 30/60
515	"	1	15	E. NAIDON	M. POLISKIN 1958	9	6	100	15	4	30	F	FARM.	HARDPAN 0-15 GRAVEL 15-19 LIMESTONE 19-100 WATER AT 75
516	"	2	1	HARMAN OLSERMAN	R. BOUAGROIS 1962	9	4	39	12	5	13	F	FARM.	CLAY GRAVEL 0-6 HARDPAN 6-9 BLACK CLAY 9-39 WATER AT 36
517	"	2	1	DIRK TESTERWIK	A. GAUTHIER 1967	9	4	42	8	6	20	F	D	HARDPAN 0-23 LIMESTONE 23-42 WATER AT 40
518	"	2	3	ST. PAGUETTE	A. GAUTHIER 1958	9	4	54	10	0.7	10	F	D	HARDPAN 0-7 LIMESTONE 7-54 WATER AT 54
519	"	2	2	PAUL LANG	R. CASSELMAN 1963	9	5	104.5	32	15	32	F	D	OLD WELL 0-30 LIMESTONE 30-104.5 WATER AT 100

TABLE OF WATER WELL RECORDS

Well No.	Location		Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
20	TOWNSHIP OF FINCH	2 9	DONALD MACINTYRE	M. LEDUC 1952	?	4	120	8	2.5	60	F	D	HARDPAN 0-20 LIMESTONE 20-120 WATER AT 100.
21	"	2 11	ANNA CHENE	A. GANTHER 1965	?	4	46	7	5	15	F	D	HARDPAN 0-15 LIMESTONE 15-46 WATER AT 45
22	"	2 11	CARL BELKSTEAD	R. CASSELMAN 1965	?	4	44	3	16.6	11	F	D	CLAY GRAVEL SANDS LIMESTONE 20-44 WATER AT 34
24	"	2 13	ST. LUKES CHURCH	M. LEDUC	?	4	37	12	5	12	F	CHICKEN	HARDPAN 0-12 LIMESTONE 12-37 WATER AT 35
27	"	2 14	CHARLES BROWNELL	M. LEDUC 1957	?	4	25	6	5	6	S	D	CLAY 0-10 HARDPAN 10-21 LIMESTONE 21-25 WATER AT 23
28	"	2 14	HEARIE MARTIN	R. BOURGEOIS 1962	?	4	37	3	5	20	F	D	GRAY GRAVEL 0-5 HARDPAN 5-13 GRAY ROCK 13-37 WATER AT 35
29	"	2 14	RAY RYANOWS	R. BOURGEOIS 1962	?	4	25	3	5	5	F	D	GRAY GRAVEL 0-4 HARDPAN 4-11 GRAY ROCK 11-25
30	"	2 15	GEORGE RUPERT	M. LEDUC 1958	?	4	63	10	1	60	S	D	CLAY 0-18 LIMESTONE 18-63 WATER AT 62
31	"	2 17	M. BEGG	M. LEDUC 1958	?	4	25	5	5	15	M	PART	HARDPAN 0-25 WATER AT 25
32	"	2 18	FINCH TWP SCREEN AREA	M. LEDUC	?	4	50	8	6.6	8	S	5 ROCK	CLAY 0-10 HARDPAN 10-30 LIMESTONE 30-50 WATER AT 42
33	"	2 18	F. ELGIN	A. GANTHER 1955	?	4	190		DRY				HARDPAN 0-22 LIMESTONE 22-190
34	"	2 20	M. PRICE	M. LEDUC 1949	?	4	30	OVERFLOWING			F	D	WHITE CLAY 0-10 HARDPAN 10-30

# ONTARIO WATER RESOURCES COMMISSION

## TABLE OF WATER WELL RECORDS

AREA OF SURVEY TOWNSHIP OF FINCH

COUNTY STORMONT

DATE JAN 17/1

RECORDED P.F.M.

Well No.	Location		Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
535	TOWNSHIP OF FINCH	2 20	DON CAMBEAL	A. GAUTHIER 1950	9	4	50	10	8.3	25	F	W.	DUG WELL 0-10 ROCK 10-50
536	"	2 21	DEPT OF HIGHWAYS ONTARIO	R. CASSELMAN	9	6	103	4	16.6	33	F	W.	CONCRETE HARDPAN 0-10 SAND 10-20 CLAY GRAVEL 20-25 LIMESTONE 25-30 WATER AT 30
537	"	3 3	CHENON SMITH	R. CASSELMAN 1965	9	6	62	14	8.3	52	F	FAEN & D.	DUG WELL 0-21 CLAY GRAVEL 21-24 LIMESTONE 24-62
538	"	3 5	M. MARLELLUS	BOURQUEOIS 1960 SANCHE	9	4	30	10	2	20	F	D	DEPT CLAY 0-10 HARDPAN 10-12 SAND 12-15 CLAY LIMESTONE 15-30 WATER AT 19
539	"	3 7	DIANE MACLEAN	M. LEDUC 1952	9	4	23	6	6.6	6	F	D	HARDPAN 0-20 LIMESTONE 20-23 WATER AT 17
540	"	3 9	STUART DUFF	A. GAUTHIER 1960	9	4	80	25	1.5	70	F	D	HARDPAN 0-7 LIMESTONE 7-80 WATER AT 70
541	"	3 9	TERESA M. MAHAN	A. GAUTHIER 1963	9	4	89	50	1.5	74	F	D	HARDPAN 0-3 LIMESTONE 3-89 WATER AT 70
542	"	3 9	FRANCOIS BERGUALE	M. LEDUC 1953	9	4	26	4	6.6	8	F	D	CLAY HARDPAN 0-20 LIMESTONE 20-26
543	"	3 10	ALCIDE CUEVILLERES	M. LEDUC 1958	9	4	28	8	5	8	M	W.	WATER AT 26 HARDPAN 0-26 CLAY 26-28 WATER AT 28
544	"	3 10	CHARLES OUDERKIRK	A. GAUTHIER 1960	9	4	75	5	5	31	F	D	HARDPAN 0-20 SAND 20-22 LIMESTONE 22-25 WATER AT 25
545	"	3 12	MARCO OUDERKIRK	R. CASSELMAN 1966	9	5	76	5	8.3	21	F	D	CLAY 0-5 CLAY LIMESTONE 5-14 LIMESTONE 14-76
546	"	3 12	PAUL LALONDE	A. GAUTHIER 1966	9	4	39	7	1.2	25	F	D	WATER AT 66 HARDPAN 0-19 LIMESTONE 19-35 WATER AT 32

# ONTARIO WATER RESOURCES COMMISSION

AREA OF SURVEY SPENCER  
COUNTY SPENCER

DATE JAN 171  
RECORDER D.C.M.

## TABLE OF WATER WELL RECORDS

Well No.	Location		Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
547	TOWNSHIP OF FINCH	3 13	ALDO WILFRED	M. LEBEL 1950	?	4	48	8	3.3	-	M	?	HARDPAN 0-35 LIMESTONE 35-45 WATER AT 40
548	"	3 13	ROY REVARDT	M. LEBEL 1958	?	4	92	8	1.03				HARDPAN 0-20 LIMESTONE 20-92 WATER AT 92
551	"	3 13	JAN MACINTOSH	A. GAUTHIER 1964	?	4	130	-	DRY	-	-	-	HARDPAN 0-5 LIMESTONE 5-130
552	"	3 13	P.J. BENDER	A. GAUTHIER 1966	?	4	45	5	10	20	F	?	HARDPAN 0-15 LIMESTONE 15-45 WATER AT 40
556	"	3 14	CARL WALDROFF	M. CAYEY 1969	?	4	110	10	CAN	BE PUMPED DRY	F	?	TOP SOIL 0-5 LIMESTONE 5-110 WATER AT 45
557	"	3 14	GEORGE KIRNEY	R. BOULGEOIS 1962	?	4	26	10	5	13	F	?	YELLOW SAND 0-5 HARDPAN 5-20 CLAY 20-24 GRAVEL 24-26 WATER AT 24
558	"	3 14	UNITED COUNTIES REPAIR SHOP	R. CASSELMAN 1962	?	6.7	153	5	10	90	S	?	BELOVED CLAY 0-18 LIMESTONE 18-153
559	"	3 15	ANDRAY HOTT	M. LEBEL 1953	?	4	38	20	3.3	20	F	?	HARDPAN 0-135 LIMESTONE 135-14 WATER AT 37
560	"	3 15	DALTON MCHINMAN	A. GAUTHIER 1960	?	4	40	15	1	35	F	?	HARDPAN 0-5 LIMESTONE 5-40 WATER AT 30
561	"	3 16	LADISAY HOTT	BOURGEOIS 1962	?	5	28	10	5	15	F	?	YELLOW SAND 0-5 HARDPAN 5-25 GRAVEL 25-28 WATER AT 28
562	"	4 2	JOSEPH MANLEY	A. GAUTHIER 1961	?	4	52	10	12	15	F	?	HARDPAN 0-3 LIMESTONE 3-52 WATER AT 50
563	"	4 4	ANTONIS SANDERS	A. GAUTHIER 1961	?	5	65	5	20	10	F	?	HARDPAN 0-35 LIMESTONE 35-65 WATER AT 60

ONTARIO WATER RESOURCES COMMISSION

TABLE OF WATER WELL RECORDS

DATE JAN/71

RECORDER P.M.

AREA OF SURVEY STORM

COUNTY STORM

Well No.	Location		Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
564	TOWNSHIP OF FULLH	4	DREWY MCBEE	R. CASSELLMAN 1936	1	5	259		DRY				CLAY LIMESTONE 9-359
565	"	4	DREWY MCBEE	R. CASSELLMAN 1936	1	5	150	9	0.83	80	F	D	TOBACCO 0-3 CLAY LIMESTONE 3-150 WATER AT 80.
566	"	4	DONALD DINGWALL	A. GAUTHIER 1959	1	4	50	18	3.3	40	F	PH	HAROPAN 0-21 LIMESTONE 21-50 WATER AT 45.
567	"	4	BEAUNE OUTREKURK	M. LEOUX 1951	1	4	65	6	1.7	-	M	-	LIMESTONE 0-65
568	"	5	WILLIAM MORINETY	A. GAUTHIER 1957	0	4	37	20	0.67	28	F	D	HAROPAN 0-36 GRAVEL 36-37 WATER AT 37
569	"	5	SCHOOL NO. 8	BOURQUEIOS 1959	0	5	30	5	2.5	5	F	PH	GREY CLAY 0-10 HAROPAN 10-20 BUCK SAND 20-30 WATER AT 30.
570	"	5	RAYMOND HAMMILL	A. GAUTHIER 1948	0	4	35	10	PAIR	-	F	PH	BIG HALL 0-20 HAROPAN 20-35 WATER AT 35.
571	"	5	ARNOLD MECHANATHAN	M. LEOUX 1952	1	4	106	6	-	-	S	PH	HAROPAN 0-4 LIMESTONE 4-106 WATER AT 6.
572	"	5	ARNOLD MACINTOSH	BOURQUEIOS 1960	1	4	178	38	5	45	S	PH	GREY CLAY 0-10 HAROPAN 10-15 SAND 15-18 LIMESTONE 18-178 WATER AT 40.
573	"	5	J. PALLON	M. LEOUX 1955	1	4	69	9	1	CAN PUMP DRY	F	D	HAROPAN 0-6 DARK GREY LIMESTONE 6-6
574	"	5	SCHOOL NO. 4	BOURQUEIOS 1959	1	5	173	8	30	8	S	PH	GREY CLAY 0-10 HAROPAN 10-43 GREY LIMESTONE 43-173 WATER AT 173
575	"	5	A. V. EMPEY	M. LEOUX 1950	1	4	65	6	3	-	S	D	HAROPAN 0-31 LIMESTONE 31-65 WATER AT 62

AREA OF SURVEY

COUNTY STERMONT

TABLE OF WATER WELL RECORDS

DATE

JAN/71

RECORDER

D.C.M.

Well No.	Location		Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
576	TOWNSHIP OF FINCH	5 14	OSCAR GODARD	A. GAUTHIER 1963	1	4	38	10	8	30	F	1	HARDPAN 0-28.5 LIMESTONE 28.5-38 WATER AT 36
577	"	5 15	CLAUDE MELDRUM	M. LEBLANC 1957	1	4	35	8	5	8	F	1	CLAY 0-20 SAND 20-32 GRAVEL 32-35 WATER AT 35
578	"	5 16	ERICH BEAUMONT	A. GAUTHIER 1963	1	4	33	3	15	20	F	1	HARDPAN 0-32 GRAVEL 32-33 WATER AT 33
581	"	6 3	CHAS. GRADY	M. LEBLANC 1952	1	4	50	6	9.3	6	S	1	CLAY 0-25 HARDPAN 25-45 GRAVEL 45-50 WATER AT 50
580	"	6 7	GILBERT CASSELMAN	M. LAYEL 1960	1	5	80	15	12	35	F	1	DLK WALL 0-14 LIMESTONE 14-80 WATER AT 75
582	"	6 13	SERGE KARAR	GAUTHIER 1968 + CAYER	1	4	45	10	-	-	F	1	ROCK 0-45 WATER AT 40
583	"	6 13	PERCY MCLISOD	M. LEBLANC 1953	1	4	38	20	3.3	-	F	1	HARDPAN 0-30 GRAY LIMESTONE 30-38 WATER AT 30
584	"	6 13	UBALD LALANDE	M. LEBLANC 1954	1	4	25	13	5	13	F	1	HARDPAN 0-21 GRAVEL 21-25 WATER AT 13
585	"	6 13	ARNOLD ENRIET	R. BOULANGER 1961	1	5	45	6	5	35	F	1	GRAY CLAY 0-5 HARDPAN 5-35 GRAVEL 35-45 LIMESTONE 45-48 WATER AT 44
586	"	6 13	ADAM ANDERSON	R. BOULANGER 1961	1	4	38	6	5	28	F	1	GRAY CLAY 0-5 HARDPAN 5-27 GRAVEL 27-38 WATER AT 38
587	"	6 13	TOWNSHIP OF FINCH	A. GAUTHIER 1967	1	5	64	15	5	55	S	1	HARDPAN 0-34 LIMESTONE 34-60 WATER AT 60
588	"	6 14	BETTE GRADY	GAUTHIER 1968 + CAYER	1	4	45	15	8.3	35	F	1	ROCK 0-45 WATER AT 40

AREA OF SURVEY

## ONTARIO WATER RESOURCES COMMISSION

DATE

JAN/71

COUNTY

ST. CLEMENT

## TABLE OF WATER WELL RECORDS

RECORDER

D. F. M.

Well No.	Location			Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
589	TOWNSHIP OF FINCH	6	14	MACQUEEN BROS.	M. LEDUC 1951	•	4	33	8	5	15	F	D	GRAVEL 0-53
590	"	6	14	CATHERINE MACQUEEN	M. LEDUC 1954	•	4	35	11	5	14	F	D	GRAVEL 0-15 HARD PAN 15-32 GRAVEL 32-35 WATER AT 34
591	"	6	14	R. LARUE	M. LEDUC 1957	•	4	37	24	3.3	24	F	D	CLAY 0-15 HARD PAN 15-32 LIMESTONE 32-37 WATER AT 36
592	"	6	14	B. MC ANTHON	M. LEDUC 1957	•	4	41	33	0.33	41	F	D	HARD PAN 0-41 WATER AT 41
593	"	6	14	R. COLEMAN	M. LEDUC 1957	•	4	41	11	3.3	11	F	D	HARD PAN 0-37 LIMESTONE 37-41 WATER AT 40
594	"	6	14	B. RAEY	BOURGEOIS & CAYER 1957	•	4	98	6	13.3	20	S	D	CLAY 0-15 HARD PAN 15-40 LIMESTONE 40-95 WATER AT 95
595	"	6	14	BERNARD DUTH	A. GANTHIER 1958	•	4	42	16	8.3	25	F	D	HARD PAN 0-37 LIMESTONE 37-42 WATER AT 41
596	"	6	14	KRAFT FOODS LTD	J. DUFRESNE 1959	•	8	177	13	-	-	F	FACTORY	CLAY + STONE 0-37 GRAVEL + SAND 37-40 LIMESTONE 40-177 WATER AT 37/100
597	"	6	14	DON SMITH	BOURGEOIS & SANILA 1959	•	5	110			DRY		D	CLAY & PEBBLES 0-12 LIMESTONE 12-110
598	"	6	14	CARMEL SIMILAR	M. CAYER 1959	•	5	120			DRY		FARM	HARD PAN 0-12 LIMESTONE 12-120
599	"	6	14	KRAFT FOODS LTD	B. SPARKS 1959	•	8	277	10	25	35	F	FACTORY	GRANITE 0-177 BROWN LIMESTONE 177-260 GRAY LIMESTONE 260-277 WATER AT 270
600	"	6	14	ANGUS MC GERNY	A. GANTHIER 1963	•	4	43	20	10	30	F	D	HARD PAN 0-40 LIMESTONE 40-43 WATER AT 40



ONTARIO WATER RESOURCES COMMISSION

AREA OF SURVEY

COUNTY

STORMONT

TABLE OF WATER WELL RECORDS

DATE

JAN 71

RECORDER

D.F.M.

Well No.	Location		Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
601	TOWNSHIP OF FINCH	6 14	FINCH TOWNSHIP SCHOOL	A. G. GUTHRIER 1964	9	5	70	14	5	50	S	WATER	HARD PAN 0-14 LIMESTONE 14-70 WATER AT 64
602	"	6 16	V. NAPIER	GUTHRIER & CAYEY 1950	9	4	100	20	-	-	F	WATER	LIMESTONE 0-100 WATER AT 120
603	"	6 16	FLOSSIE MENDHAM	M. LEON 1956	0	4	40	12	3.3	22	F	WATER	HARD PAN 0-25 QUICKSAND 25-37 GRAVEL 37-40 WATER AT 40
579	"	6 17	JOHNSON QUERRIER	A. G. GUTHRIER 1965	9	4	48	14	3	40	F	WATER	HARD PAN 0-17 LIMESTONE 17-45 WATER AT 38
604	"	7 5	JEAN SALOMME	A. G. GUTHRIER 1960	0	4	46.5	22	5	35	F	D	HARD PAN 0-38 QUICKSAND 38-44 GRAVEL 45-46.5 WATER AT 46.5
605	"	7 7	RHEAL LAMOURSEY	A. G. GUTHRIER 1960	0	4	53	8	8.3	30	F	WATER	HARD PAN 0-52 GRAVEL 52-53 WATER AT 53
606	"	7 8	HENRY MESSOT	A. G. GUTHRIER 1958	0	4	39	7	6.6	7	F	WATER	CLAY 0-29 HARD PAN 29-37 GRAVEL 37-39 WATER AT 39
607	"	7 12	GIAN BURNFORD	M. CAYEY 1960	9	5	66	15	8	46	F	WATER	HARD PAN 0-18 LIMESTONE 18-35 GRAVEL 35-66 WATER AT 65
608	"	7 14	RUSSELL DELLABOUGH	A. G. GUTHRIER 1964	9	5	70	15	2	15	F	WATER	HARD PAN 0-16 LIMESTONE 16-70 WATER AT 55
609	"	7 15	EDWARD MENDHAM	A. G. GUTHRIER 1958	9	4	158	10	1	155	F	D	HARD PAN 0-17 QUICKSAND 17-158 WATER AT 17
610	"	7 18	REV. PICKFORTH	M. LEON 1951	9	4	64	11	3.3	-	F	D	GRAY QUICKSAND 0-6 LIMESTONE 60-64 WATER AT 64
611	"	7 21	EUGENE CLOUTIER	M. LEON 1949	9	4	22	6	16.7	16	F	D	YELLOW SAND 0-11 BED ROCK 11-22 WATER AT 6

ONTARIO WATER RESOURCES COMMISSION

TABLE OF WATER WELL RECORDS

AREA OF SURVEY STORMONT  
COUNTY STORMONT

DATE JAN/71  
RECORDER D.F.17

Well No	Location	Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
348	TOWNSHIP OF DEWARBURG 7 14	HAROLD ARMSTRONG	M. LEUNG 1958	9	4	52	30	3.3	30	F	D	HARDMAN 0-32 LIMESTONE 32-52 WATER AT 52
349	" 7 14	HAROLD ARMSTRONG	A. GUTHRIE 1960	9	4	52	5	20	20	F	D	CLAY 0-30 LIMESTONE 30-52 WATER AT 50
350	" 7 16	GEORGE BAKER	A. CATHIER 1960	0	4	39	6	20	15	F	D	HARDMAN 0-35 GRAVEL 35-55 WATER AT 33
351	" 7 21	C. REYNOLDS	R. CASSELLMAN 1965	9	6	124	3	5	100	F	D	OLD WELL CLAY GRAVEL 0-15 LIMESTONE 15-20 WATER AT 120
852	" 8 2	CHEN WATKINS	R. CASSELLMAN 1951	9	5	131	51	5	67	F	D	OLD WELL CLAY GRAVEL 0-30 LIMESTONE 30-70 WATER AT 121
853	" 8 3	JACK HELMER	A. CAYEY 1964	9	5	77	25	2	70	F	D	HARDMAN 0-73 ROCK 73-77
854	" 8 6	OSNABROUGHT SILICO BOARD	R. CASSELLMAN 1955	9	6	208	9	20	50	F	D	TOP SOIL 0-2 CLAY GRAVEL 2-43 LIMESTONE 43-205 WATER AT 200
855	" 8 6	CHARLES DIXON	R. CASSELLMAN 1965	9	6	257	9	375	40	F	D	GRAVEL SAND LIMESTONE 40-1 WATER AT 40/210
856	" 8 7	KRAFT FOOD LTD	I. W. S. 1959	0	5	15		N/A	TEST			TOP SOIL 0-1 SANDY CLAY 1-3 CLAY GRAVEL 3-10 GRAVEL SAND 10-15
857	" 8 7	KRAFT FOOD LTD	I. W. S. 1959	9	5	34		N/A	TEST			TOP SOIL 0-1 SANDY CLAY 1-10 GRAVEL SAND 10-32 LIMESTONE 32-37

ONTARIO WATER RESOURCES COMMISSION

AREA OF SURVEY

COUNTY

STORMONT

TABLE OF WATER WELL RECORDS

DATE

JAN/71

RECORDER

D.F.M.

Well No.	Location	Owner	Driller	Well Type	Well Diameter	Depth	Static Level	Pumping Rate	Pumping Level	Quality	Use	Remarks, Log, etc.
58	TOWNSHIP OF TEMERAGUE	KEAT FOODS LTD	I. W. S. 1959	•	2	26	3	30	10	F	FACTORY	TOP SOIL, SANDY SAND, GRAVEL, CLAY, Boulders 1-13, GRAVEL SAND, Boulders 13-37, LIMESTONE WATER AT 15.000
359	"	KEAT FOODS LTD	I. W. S. 1959	•	2	23	1	13	16	F	FACTORY	TOP SOIL, SANDY SAND, GRAVEL, CLAY, Boulders 1-13, GRAVEL SAND, Boulders 13-37, LIMESTONE WATER AT 15.000
360	"	KEAT FOODS LTD	I. W. S. 1959	•	5	13		NO	TEST			TOP SOIL, SANDY SAND, GRAVEL, CLAY, Boulders 1-13
361	"	KEAT FOODS LTD	I. W. S. 1959	•	5	21		NO	TEST			TOP SOIL, SANDY SAND, GRAVEL, CLAY, Boulders 1-21
362	"	KEAT FOODS LTD	I. W. S. 1959	•	5	36		NO	TEST			TOP SOIL, SANDY SAND, GRAVEL, CLAY, Boulders 1-36
363	"	UNITED CHURCH	M. CATER 1964	•	5	41	15	5	20	F	CHURCH	TOP SOIL, SANDY SAND, GRAVEL, CLAY, Boulders 1-36, SANDY SAND, GRAVEL, CLAY, Boulders 36-41, WATER AT 41
364	"	FRED CLARMENT	A. GAUTHIER 1964	•	4	45	5	5	30	F	•	WATER AT 42, LIMESTONE 34-45
365	"	KEAT FOODS LTD	C. MORRISON 1954	•	10	22		DEY				WATER AT 42, BLACK EARTH 0-2
366	"	BELFC ANDREE	A. BOURBON 1954	•	5	105	9	4.1	9	F	•	CLAY, GRAVEL 0-33, BLACK SLATE 33-405, WATER AT 41
367	"	RUSSEL PRINGLEY	A. GAUTHIER 1962	•	4	38	4	3	25	F	•	WATER AT 41, LIMESTONE 24-35, WATER AT 37

[illegible]

## **APPENDIX I**

### **Photolog**



NORTH ALONG WILLIAM ST. TOWARDS  
WELDING SHOP. FINCH WATER SUPPLY  
BUILDING AT RIGHT OF PHOTOGRAPH



SANDBLASTER SHOP ACROSS ROAD FROM  
SITE (LOOKING NORTHWEST)




PUMPHOUSE & TREATMENT PLANT (FINCH)



WELDER TO NORTH OF SITE



LOOKING SOUTHWEST FROM NORTHEAST SIDE  
OF ARENA (WATER TOWER IN BACKGROUND)



VACANT LOT ON EAST SIDE OF GEORGE  
ACROSS STREET FROM ARENA (JUST NORTH  
OF JOHN STREET)





EAST SIDE OF WELDER TO NORTH ON WEST SIDE OF GEORGE STREET LOOKING NORTHWEST



LOOKING EAST (CORNER OF GEORGE AND JOHN ST.) FROM SOUTHEAST CORNER OF ARENA



LOOKING NORTHWEST AT NORTHWEST CORNER OF MAIN & GEORGE AT OLD GAS STATION SITE (WATER TOWER IN BACKGROUND)



LOOKING EAST ALONG HWY 43 COMMERCIAL BUSINESSES (CORNER OF MAIN & HWY 43)




UST AT BACK OF BANK LOOKING WEST NORTHWEST (WATER TOWER IN BACKGROUND)




LOOKING WEST ALONG HWY 43 (CORNER OF MAIN & HWY 43)






LOOKING NORTH ALONG WILLIAM ST. FUNERAL HOME  
(FROM HWY 43) WATER TOWER IN BACKGROUND



WATER TOWER FROM HWY 43 LOOKING NORTH




ARENA LOOKING NORTHEAST FROM WILLIAM ST. WATER  
SUPPLY BUILDING AHEAD



RAISED TILE BED - EAST SIDE OF WILLIAM STREET, CORNER OF WILLIAM  
AND JOHN JUST NORTH OF JOHN ACROSS STREET FROM ARENA





UST AT BACK OF HOUSE EAST SIDE OF  
WILLIAM JUST SOUTH OF ARENA



BEST SHOT (LIBRARY HOURS)  
VERY USEFUL!



LOOKING NORTHWEST FROM ARENA PARKING LOT  
JUST SOUTH OF PUMPHOUSE



ARENA LOOKING NORTHEAST FROM WILLIAM ST.  
WATER SUPPLY BUILDING AHEAD

July 11, 2005  
Project # B3018

Township of North Stormont  
2 Victoria Street  
P.O. Box 99  
Berwick, Ontario  
K0C 1G0

**Attn: Mr. Rheal Charbonneau, Clerk-Treasurer**

**Re: Final Report  
Proposed Well Head Protection Plan  
Village of Finch Municipal Groundwater Supply Wells**


Dear Mr. Charbonneau:

Please find attached two copies of the above captioned report. Additional copies of the report have been distributed as follows:

- 1 copy to Jan Franssen, Drinking Water Inspector, MOE Cornwall
- 1 copy to Blair Henderson, OCWA
- 1 copy to Jim Johnston, Genivar Consulting Group

An electronic copy of the report (PDF format on CD) will also be forwarded to the Township and to the South Nation Conservation Authority. If you have any questions, please do not hesitate to contact the undersigned.

Respectfully,



Robert J. Hillier, B.Sc., P.Geo.  
Senior Hydrogeologist

**Cc: James Johnston, Genivar Consulting Group  
Blair Henderson, OCWA – Chesterville Hub  
Jan Franssen, MOE Cornwall**

*Ref: B3018 July 11-05.doc*